



Instruction Manual for Portable Compressors English

XAHS 146 Dd - XAHS 300 DD6
XATS 156 Dd - XATS 350 DD6
XA(S) 186 Dd - XA(S) 375 DD6
XAVS 166 Dd - XAVS 340 DD6
XAHS 186 Dd - XAHS 375 DD6

Engine Deutz
TCD

XATS 156 Dd - XATS 350 DD6
XA(S) 186 Dd - XA(S) 375 DD6

Engine Deutz
BF4M

Instruction Manual for Portable Compressors

**XAHS 146 Dd
XATS 156 Dd
XA(S) 186 Dd
XAVS 166 Dd
XAHS 186 Dd**

Original instructions

Printed matter N°
2954 2230 07

11/2014



ATLAS COPCO - PORTABLE ENERGY DIVISION
www.atlascopco.com

Warranty and Liability Limitation

Use only authorized parts.

Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.

The manufacturer does not accept any liability for any damage arising from modifications, additions or conversions made without the manufacturer's approval in writing.

Neglecting maintenance or making changes to the setup of the machine can result in major hazards, including fire risk.

While every effort has been made to ensure that the information in this manual is correct, Atlas Copco does not assume responsibility for possible errors.

Copyright 2014, Atlas Copco Airpower n.v., Antwerp, Belgium.

Any unauthorized use or copying of the contents or any part thereof is prohibited.

This applies in particular to trademarks, model denominations, part numbers and drawings.

Preface

Follow the instructions in this booklet and we guarantee you years of troublefree operation. It is a solid, safe and reliable machine, built according to the latest technology.

Always keep the manual available near the machine.

In all correspondence always mention the compressor type and serial number, shown on the data plate.

The company reserves the right to make changes without prior notice.

CALIFORNIA Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Table of contents

1	Safety precautions	7
1.1	Introduction	7
1.2	General safety precautions	8
1.3	Safety during transport and installation	9
1.4	Safety during use and operation	10
1.5	Safety during maintenance and repair	11
1.6	Tool applications safety	12
1.7	Specific safety precautions	13
2	Leading particulars	14
2.1	Description of safety pictograms used in this manual 14	
2.2	General description	14
3	Main Parts	16
3.1	Compressor regulating system	20
3.1.1	Overview (Load condition)	20
3.1.2	Air flow	21
3.1.3	Oil system	21
3.1.4	Continuous regulating system	22
3.2	Electrical system	24
3.2.1	Dip switches for XAHS 146 Dd, XATS 156 Dd and XA(S) 186 Dd 25	
3.2.2	Dip switches for XAVS 166 Dd and XAHS 186 Dd 25	
3.3	Markings and information labels	26
4	Operating instructions	27
4.1	Parking, towing and lifting instructions	27
4.1.1	Parking instructions	27

4.1.2	Towing instructions	28
4.1.3	Height adjustment	29
4.1.4	Instructions ball coupling (option)	30
4.1.5	Lifting instructions	30
4.2	Starting/Stopping	31
4.2.1	Before starting	31
4.2.2	Control panel	31
4.2.3	During operation	32
5	Maintenance	33
5.1	Use of service paks	33
5.2	Preventive maintenance schedule for the compressor 33	
5.3	Oil specifications	37
5.3.1	Compressor oil	38
5.3.2	Engine oil	38
5.3.3	Compressor oil level check	39
5.3.4	Daily check	39
5.3.5	Check after a longer period without running the compressor 39	
5.4	Engine oil	40
5.4.1	Engine oil level check	40
5.4.2	Engine oil and oil filter change	40
5.4.3	Compressor oil and oil filter change	40
5.5	Compressor Oil Flushing Procedure	41
5.6	Coolant specifications	42
5.6.1	PARCOOL EG	42
5.6.2	Handling PARCOOL EG	43
5.7	Coolant check	43
5.8	Topping up/replacing coolant	43
5.8.1	Topping up without draining from the cooling system 44	
5.8.2	Topping up after limited quantity draining from the cooling system 45	

5.8.3	Replacing the coolant	46	6.8.3	Wheel bolts check	55
5.9	Cleaning coolers	46	6.8.4	Wheel bearing adjustment.....	56
5.10	Battery care	47	6.9	Towbar and overrun brake	57
5.10.1	Electrolyte	47	6.9.1	Towbar and overrun brake check.....	57
5.10.2	Activating a dry-charged battery.....	47	6.9.2	Lubrication	58
5.10.3	Recharging a battery	47			
5.10.4	Make-up distilled water.....	47	7	Problem solving	60
5.10.5	Periodic battery service	47	8	Available options	63
5.11	Storage	48	9	Technical specifications	64
5.12	Service paks.....	48	9.1	Torque values	64
5.13	Service kits	48	9.1.1	For general applications	64
5.14	Compressor element overhaul	48	9.1.2	Critical torque values	64
5.15	Liability	48	9.2	Settings of shutdown switches and safety valves 65	
6	Adjustments and servicing procedures ..	49	9.3	Compressor/Engine/Generator specifications .	66
6.1	Adjustment of the continuous regulating system 49		9.3.1	Reference conditions.....	66
6.2	Air filter engine/compressor.....	50	9.3.2	Limitations	66
6.2.1	Cleaning the dust trap	50	9.3.3	Performance data	67
6.2.2	Recommendations	50	9.3.4	Design data.....	69
6.2.3	Replacing the air filter element	50			
6.3	Air receiver.....	50	10	Data plate	71
6.4	Safety valve	50	11	Disposal	72
6.5	Fuel system.....	51	11.1	General	72
6.5.1	Fuel.....	51	11.2	Disposal of materials.....	72
6.6	Brake (= option) adjustment.....	51	12	Maintenance Log	73
6.7	Brake shoe adjustment.....	51			
6.7.1	Test procedure of brake cable adjustment... 52				
6.7.2	Brake cable adjustment	53			
6.8	Wheels	54			
6.8.1	Wheel check	54			
6.8.2	Lubrication	54			

Safety precautions



To be read attentively and acted accordingly before towing, lifting, operating, performing maintenance or repairing the unit.

INTRODUCTION

The policy of Atlas Copco is to provide the users of their equipment with safe, reliable and efficient products. Factors taken into account are among others:

- the intended and predictable future use of the products, and the environments in which they are expected to operate,
- applicable rules, codes and regulations,
- the expected useful product life, assuming proper service and maintenance,
- providing the manual with up-to-date information.

Before handling any product, take time to read the relevant instruction manual. Besides giving detailed operating instructions, it also gives specific information about safety, preventive maintenance, etc.

Keep the manual always at the unit location, easy accessible to the operating personnel.

See also the safety precautions of the engine and possible other equipment, which are separately sent along or are mentioned on the equipment or parts of the unit.

These safety precautions are general and some statements will therefore not always apply to a particular unit.

Only people that have the right skills should be allowed to operate, adjust, perform maintenance or repair on Atlas Copco equipment.

It is the responsibility of management to appoint operators with the appropriate training and skill for each category of job.

Skill level 1: Operator

An operator is trained in all aspects of operating the unit with the push-buttons, and is trained to know the safety aspects.

Skill level 2: Mechanical technician

A mechanical technician is trained to operate the unit the same as the operator. In addition, the mechanical technician is also trained to perform maintenance and repair, as described in the instruction manual, and is allowed to change settings of the control and safety system. A mechanical technician does not work on live electrical components.

Skill level 3: Electrical technician

An electrical technician is trained and has the same qualifications as both the operator and the mechanical technician. In addition, the electrical technician may carry out electrical repairs within the various enclosures of the unit. This includes work on live electrical components.

Skill level 4: Specialist from the manufacturer

This is a skilled specialist sent by the manufacturer or its agent to perform complex repairs or modifications to the equipment.

In general it is recommended that not more than two people operate the unit, more operators could lead to unsafe operating conditions.

Take necessary steps to keep unauthorized persons away from the unit and eliminate all possible sources of danger at the unit.

When handling, operating, overhauling and/or performing maintenance or repair on Atlas Copco equipment, the mechanics are expected to use safe engineering practices and to observe all relevant local safety requirements and ordinances. The following list is a reminder of special safety directives and precautions mainly applicable to Atlas Copco equipment.

These safety precautions apply to machinery processing or consuming air. Processing of any other gas requires additional safety precautions typical to the application and are not included herein.

Neglecting the safety precautions may endanger people as well as environment and machinery:

- endanger people due to electrical, mechanical or chemical influences,
- endanger the environment due to leakage of oil, solvents or other substances,
- endanger the machinery due to function failures.

All responsibility for any damage or injury resulting from neglecting these precautions or by non-observance of ordinary caution and due care required in handling, operating, maintenance or repair, also if not expressly mentioned in this instruction manual, is disclaimed by Atlas Copco.

The manufacturer does not accept any liability for any damage arising from the use of non-original parts and for modifications, additions or conversions made without the manufacturer's approval in writing.

If any statement in this manual does not comply with local legislation, the stricter of the two shall be applied.

Statements in these safety precautions should not be interpreted as suggestions, recommendations or inducements that it should be used in violation of any applicable laws or regulations.

GENERAL SAFETY PRECAUTIONS

- 1 The owner is responsible for maintaining the unit in a safe operating condition. Unit parts and accessories must be replaced if missing or unsuitable for safe operation.
- 2 The supervisor, or the responsible person, shall at all times make sure that all instructions regarding machinery and equipment operation and maintenance are strictly followed and that the machines with all accessories and safety devices, as well as the consuming devices, are in good repair, free of abnormal wear or abuse, and are not tampered with.
- 3 Whenever there is an indication or any suspicion that an internal part of a machine is overheated, the machine shall be stopped but no inspection covers shall be opened before sufficient cooling time has elapsed; this to avoid the risk of spontaneous ignition of oil vapour when air is admitted.
- 4 Normal ratings (pressures, temperatures, speeds, etc.) shall be durably marked.
- 5 Operate the unit only for the intended purpose and within its rated limits (pressure, temperature, speeds, etc.).
- 6 The machinery and equipment shall be kept clean, i.e. as free as possible from oil, dust or other deposits.
- 7 To prevent an increase in working temperature, inspect and clean heat transfer surfaces (cooler fins, intercoolers, water jackets, etc.) regularly. See the **Preventive maintenance schedule for the compressor**.
- 8 All regulating and safety devices shall be maintained with due care to ensure that they function properly. They may not be put out of action.

- 9 Care shall be taken to avoid damage to safety valves and other pressure-relief devices, especially to avoid plugging by paint, oil coke or dirt accumulation, which could interfere with the functioning of the device.
- 10 Pressure and temperature gauges shall be checked regularly with regard to their accuracy. They shall be replaced whenever outside acceptable tolerances.
- 11 Safety devices shall be tested as described in the maintenance schedule of the instruction manual to determine that they are in good operating condition. See the **Preventive maintenance schedule for the compressor**.
- 12 Mind the markings and information labels on the unit.
- 13 In the event the safety labels are damaged or destroyed, they must be replaced to ensure operator safety.
- 14 Keep the work area neat. Lack of order will increase the risk of accidents.
- 15 When working on the unit, wear safety clothing. Depending on the kind of activities these are: safety glasses, ear protection, safety helmet (including visor), safety gloves, protective clothing, safety shoes. Do not wear the hair long and loose (protect long hair with a hairnet), or wear loose clothing or jewellery.
- 16 Take precautions against fire. Handle fuel, oil and anti-freeze with care because they are inflammable substances. Do not smoke or approach with naked flame when handling such substances. Keep a fire-extinguisher in the vicinity.

SAFETY DURING TRANSPORT AND INSTALLATION

Transport of the unit has to be done by authorized/experienced people.

When towing, lifting or transporting the compressor in any way, the battery switch must always be switched off.

To lift a unit, all loose or pivoting parts, e.g. doors and towbar, shall first be securely fastened.

Do not attach cables, chains or ropes directly to the lifting eye; apply a crane hook or lifting shackle meeting local safety regulations. Never allow sharp bends in lifting cables, chains or ropes.

Helicopter lifting is not allowed.

It is strictly forbidden to dwell or stay in the risk zone under a lifted load. Never lift the unit over people or residential areas. Lifting acceleration and retardation shall be kept within safe limits.

1 Before towing the unit:

- ascertain that the pressure vessel(s) is (are) depressurized,
- check the towbar, the brake system and the towing eye. Also check the coupling of the towing vehicle,
- check the towing and brake capability of the towing vehicle,
- check that the towbar, jockey wheel or stand leg is safely locked in the raised position,
- keep hands/fingers away from the coupling device and all other potential pinch points. Keep feet away from the towbar to avoid injury if it should slip,
- ascertain that the towing eye can swivel freely on the hook,

- check that the wheels are secure and that the tyres are in good condition and inflated correctly,
 - connect the signalisation cable, check all lights and connect the pneumatic brake couplers, ascertain that the signalisation cable can not drag on the ground when towing the unit,
 - attach the safety break-away cable or safety chain to the towing vehicle,
 - remove wheel chocks, if applied, and disengage the parking brake,
 - check whether springs on wheelchocks are missing or broken.
- 2 To tow a unit use a towing vehicle of ample capacity. Refer to the documentation of the towing vehicle.
 - 3 If the unit is to be backed up by the towing vehicle, disengage the overrun brake mechanism (if it is not an automatic mechanism).
 - 4 Never exceed the maximum towing speed of the unit (mind the local regulations).
 - 5 Place the unit on level ground and apply the parking brake before disconnecting the unit from the towing vehicle. Unclip the safety break-away cable or safety chain. If the unit has no parking brake or jockey wheel, immobilize the unit by placing chocks in front of and/or behind the wheels. When the towbar can be positioned vertically, the locking device must be applied and kept in good order. The unit must always be used/parked/stored in a non publicly accessible area, locked away from access by unauthorized persons.
 - 6 To lift heavy parts, a hoist of ample capacity, tested and approved according to local safety regulations, shall be used.

- 7 Lifting hooks, eyes, shackles, etc., shall never be bent and shall only have stress in line with their design load axis. The capacity of a lifting device diminishes when the lifting force is applied at an angle to its load axis.
- 8 For maximum safety and efficiency of the lifting apparatus all lifting members shall be applied as near to perpendicular as possible. If required, a lifting beam shall be applied between hoist and load.
- 9 Never leave a load hanging on a hoist.
- 10 A hoist has to be installed in such a way that the object will be lifted perpendicular. If that is not possible, the necessary precautions must be taken to prevent load-swinging, e.g. by using two hoists, each at approximately the same angle not exceeding 30° from the vertical.
- 11 Locate the unit away from walls. Take all precautions to ensure that hot air exhausted from the engine and driven machine cooling systems cannot be recirculated. If such hot air is taken in by the engine or driven machine cooling fan, this may cause overheating of the unit; if taken in for combustion, the engine power will be reduced.
- 12 Before moving the compressor, switch it off.

SAFETY DURING USE AND OPERATION

- 1 When the unit has to operate in a fire-hazardous environment, each engine exhaust has to be provided with a spark arrestor to trap incendiary sparks.
- 2 The exhaust contains carbon monoxide which is a lethal gas. When the unit is used in a confined space, conduct the engine exhaust to the outside atmosphere by a pipe of sufficient diameter; do this in such a way that no extra back pressure is created for the engine. If necessary, install an extractor. Observe any existing local regulations. Make sure that the unit has sufficient air intake for operation. If necessary, install extra air intake ducts.
- 3 When operating in a dust-laden atmosphere, place the unit so that dust is not carried towards it by the wind. Operation in clean surroundings considerably extends the intervals for cleaning the air intake filters and the cores of the coolers.
- 4 Close the compressor air outlet valve before connecting or disconnecting a hose. Ascertain that a hose is fully depressurized before disconnecting it. Before blowing compressed air through a hose or air line, ensure that the open end is held securely, so that it cannot whip and cause injury.
- 5 The air line end connected to the outlet valve must be safeguarded with a safety cable, attached next to the valve.
- 6 No external force may be exerted on the air outlet valves, e.g. by pulling on hoses or by installing auxiliary equipment directly to a valve, e.g. a water separator, a lubricator, etc. Do not step on the air outlet valves.
- 7 Never move a unit when external lines or hoses are connected to the outlet valves, to avoid damage to valves, manifold and hoses.
- 8 Do not use compressed air from any type of compressor, without taking extra measures, for breathing purposes as this may result in injury or death. For breathing air quality, the compressed air must be adequately purified according to local legislation and standards. Breathing air must always be supplied at stable, suitable pressure.
- 9 Distribution pipework and air hoses must be of correct diameter and suitable for the working pressure. Never use frayed, damaged or deteriorated hoses. Replace hoses and flexibles before the lifetime expires. Use only the correct type and size of hose end fittings and connections.
- 10 If the compressor is to be used for sand-blasting or will be connected to a common compressed-air system, fit an appropriate non-return valve (check valve) between compressor outlet and the connected sand-blasting or compressed-air system. Observe the right mounting position/direction.
- 11 Before removing the oil filler plug, ensure that the pressure is released by opening an air outlet valve.
- 12 Never remove a filler cap of the cooling water system of a hot engine. Wait until the engine has sufficiently cooled down.
- 13 Never refill fuel while the unit is running, unless otherwise stated in the Atlas Copco Instruction Book (AIB). Keep fuel away from hot parts such as air outlet pipes or the engine exhaust. Do not smoke when fuelling. When fuelling from an automatic pump, an earthing cable should be connected to the unit to discharge static electricity. Never spill nor leave oil, fuel, coolant or cleansing agent in or around the unit.
- 14 All doors shall be shut during operation so as not to disturb the cooling air flow inside the bodywork and/or render the silencing less effective. A door should be kept open for a short period only e.g. for inspection or adjustment.
- 15 Periodically carry out maintenance works according to the maintenance schedule.
- 16 Stationary housing guards are provided on all rotating or reciprocating parts not otherwise protected and which may be hazardous to personnel. Machinery shall never be put into operation, when such guards have been removed, before the guards are securely reinstalled.
- 17 Noise, even at reasonable levels, can cause irritation and disturbance which, over a long period of time, may cause severe injuries to the nervous system of human beings. When the sound pressure level, at any point where personnel normally has to attend, is:
 - below 70 dB(A): no action needs to be taken,
 - above 70 dB(A): noise-protective devices should be provided for people continuously being present in the room,
 - below 85 dB(A): no action needs to be taken for occasional visitors staying a limited time only,
 - above 85 dB(A): room to be classified as a noise-hazardous area and an obvious warning shall be placed permanently at each entrance to alert people entering the room, for even relatively short times, about the need to wear ear protectors,
 - above 95 dB(A): the warning(s) at the entrance(s) shall be completed with the recommendation that also occasional visitors shall wear ear protectors,
 - above 105 dB(A): special ear protectors that are adequate for this noise level and the spectral composition of the noise shall be provided and a special warning to that effect shall be placed at each entrance.

- 18 The unit has parts, which may be accidentally touched by personal, of which the temperature can be in excess of 80°C (176°F). The insulation or safety guard, protecting these parts shall not be removed before the parts have cooled down to room temperature. As it is technically not possible to insulate all hot parts or to install safety guards around hot parts (e.g. exhaust manifold, exhaust turbine), the operator / service engineer must always be aware not to touch hot parts when opening a machine door.
- 19 Never operate the unit in surroundings where there is a possibility of taking in flammable or toxic fumes.
- 20 If the working process produces fumes, dust or vibration hazards, etc., take the necessary steps to eliminate the risk of personal injury.
- 21 When using compressed air or inert gas to clean down equipment, do so with caution and use the appropriate protection, at least safety glasses, for the operator as well as for any bystander. Do not apply compressed air or inert gas to your skin or direct an air or gas stream at people. Never use it to clean dirt from your clothes.
- 22 When washing parts in or with a cleaning solvent, provide the required ventilation and use appropriate protection such as a breathing filter, safety glasses, rubber apron and gloves, etc.
- 23 Safety shoes should be compulsory in any workshop and if there is a risk, however small, of falling objects, wearing of a safety helmet should be included.
- 24 If there is a risk of inhaling hazardous gases, fumes or dust, the respiratory organs must be protected and depending on the nature of the hazard, so must the eyes and skin.
- 25 Remember that where there is visible dust, the finer, invisible particles will almost certainly be present too; but the fact that no dust can be seen is not a reliable indication that dangerous, invisible dust is not present in the air.
- 26 Never operate the unit at pressures or speeds below or in excess of its limits as indicated in the technical specifications.
- 27 Do not use aerosol types of starting aids such as ether. Such use could result in an explosion and personal injury.

SAFETY DURING MAINTENANCE AND REPAIR

Maintenance, overhaul and repair work shall only be carried out by adequately trained personnel; if required, under supervision of someone qualified for the job.

- 1 Use only the correct tools for maintenance and repair work, and only tools which are in good condition.
- 2 Parts shall only be replaced by genuine Atlas Copco replacement parts.
- 3 All maintenance work, other than routine attention, shall only be undertaken when the unit is stopped. Steps shall be taken to prevent inadvertent starting. In addition, a warning sign bearing a legend such as "work in progress; do not start" shall be attached to the starting equipment. On engine-driven units the battery shall be disconnected and removed or the terminals covered by insulating caps. On electrically driven units the main switch shall be locked in open position and the fuses shall be taken out. A warning sign bearing a legend such as "work in progress; do not supply voltage" shall be attached to the fuse box or main switch.
- 4 Before dismantling any pressurized component, the compressor or equipment shall be effectively isolated from all sources of pressure and the entire system shall be relieved of pressure. Do not rely on non-return valves (check valves) to isolate pressure systems. In addition, a warning sign bearing a legend such as "work in progress; do not open" shall be attached to each of the outlet valves.
- 5 Prior to stripping an engine or other machine or undertaking major overhaul on it, prevent all movable parts from rolling over or moving.

- 6 Make sure that no tools, loose parts or rags are left in or on the machine. Never leave rags or loose clothing near the engine air intake.
- 7 Never use flammable solvents for cleaning (fire-risk).
- 8 Take safety precautions against toxic vapours of cleaning liquids.
- 9 Never use machine parts as a climbing aid.
- 10 Observe scrupulous cleanliness during maintenance and repair. Keep away dirt, cover the parts and exposed openings with a clean cloth, paper or tape.
- 11 Never weld on or perform any operation involving heat near the fuel or oil systems. Fuel and oil tanks must be completely purged, e.g. by steam-cleaning, before carrying out such operations. Never weld on, or in any way modify, pressure vessels. Disconnect the alternator cables during arc welding on the unit.
- 12 Support the towbar and the axle(s) securely if working underneath the unit or when removing a wheel. Do not rely on jacks.
- 13 Do not remove any of, or tamper with, the sound-damping material. Keep the material free of dirt and liquids such as fuel, oil and cleansing agents. If any sound-damping material is damaged, replace it to prevent the sound pressure level from increasing.
- 14 Use only lubricating oils and greases recommended or approved by Atlas Copco or the machine manufacturer. Ascertain that the selected lubricants comply with all applicable safety regulations, especially with regard to explosion or fire-risk and the possibility of decomposition or generation of hazardous gases. Never mix synthetic with mineral oil.
- 15 Protect the engine, alternator, air intake filter, electrical and regulating components, etc., to prevent moisture ingress, e.g. when steam-cleaning.
- 16 When performing any operation involving heat, flames or sparks on a machine, the surrounding components shall first be screened with non-flammable material.
- 17 Never use a light source with open flame for inspecting the interior of a machine.
- 18 Disconnect –battery-clamp before starting electrical servicing or welding (or turn battery-switch in “off” position).
- 19 When repair has been completed, the machine shall be barred over at least one revolution for reciprocating machines, several revolutions for rotary ones to ensure that there is no mechanical interference within the machine or driver. Check the direction of rotation of electric motors when starting up the machine initially and after any alteration to the electrical connection(s) or switch gear, to check that the oil pump and the fan function properly.
- 20 Maintenance and repair work should be recorded in an operator’s logbook for all machinery. Frequency and nature of repairs can reveal unsafe conditions.
- 21 When hot parts have to be handled, e.g. shrink fitting, special heat-resistant gloves shall be used and, if required, other body protection shall be applied.
- 22 When using cartridge type breathing filter equipment, ascertain that the correct type of cartridge is used and that its useful service life is not surpassed.
- 23 Make sure that oil, solvents and other substances likely to pollute the environment are properly disposed of.
- 24 Before clearing the unit for use after maintenance or overhaul, check that operating pressures, temperatures and speeds are correct and that the control and shutdown devices function correctly.

TOOL APPLICATIONS SAFETY

Apply the proper tool for each job. With the knowledge of correct tool use and knowing the limitations of tools, along with some common sense, many accidents can be prevented.

Special service tools are available for specific jobs and should be used when recommended. The use of these tools will save time and prevent damage to parts.

SPECIFIC SAFETY PRECAUTIONS

Batteries

When servicing batteries, always wear protecting clothing and glasses.

- 1 The electrolyte in batteries is a sulphuric acid solution which is fatal if it hits your eyes, and which can cause burns if it contacts your skin. Therefore, be careful when handling batteries, e.g. when checking the charge condition.
- 2 Install a sign prohibiting fire, open flame and smoking at the post where batteries are being charged.
- 3 When batteries are being charged, an explosive gas mixture forms in the cells and might escape through the vent holes in the plugs. Thus an explosive atmosphere may form around the battery if ventilation is poor, and can remain in and around the battery for several hours after it has been charged. Therefore:
 - never smoke near batteries being, or having recently been, charged,
 - never break live circuits at battery terminals, because a spark usually occurs.
- 4 When connecting an auxiliary battery (AB) in parallel to the unit battery (CB) with booster cables: connect the + pole of AB to the + pole of CB, then connect the – pole of CB to the mass of the unit. Disconnect in the reverse order.

Pressure vessels

Maintenance/installation requirements:

- 1 The vessel can be used as pressure vessel or as separator and is designed to hold compressed air for the following application:
 - pressure vessel for compressor,
 - medium AIR/OIL,and operates as detailed on the data plate of the vessel:
 - the maximum working pressure ps in bar (psi),
 - the maximum working temperature Tmax in °C (°F),
 - the minimum working temperature Tmin in °C (°F),
 - the capacity of the vessel V in l (US gal).
- 2 The pressure vessel is only to be used for the applications as specified above and in accordance with the technical specifications. Safety reasons prohibit any other applications.
- 3 National legislation requirements with respect to re-inspection must be complied with.
- 4 No welding or heat treatment of any kind is permitted to those vessel walls which are exposed to pressure.
- 5 The vessel is provided and may only be used with the required safety equipment such as manometer, overpressure control devices, safety valve, etc.
- 6 Draining of condensate shall be performed daily when vessel is in use.
- 7 Installation, design and connections should not be changed.
- 8 Bolts of cover and flanges may not be used for extra fixation.
- 9 (Pressure) vessel maintenance is to be performed by Atlas Copco.

Safety valves

- 1 All adjustments or repairs are to be done by an authorized representative of the valve supplier (see also **Preventive maintenance schedule for the compressor**).
- 2 Only trained and technically competent personnel should consider overhaul, re-set or performance testing of safety valves.
- 3 The safety valve is supplied with either a lead security seal or crimped cover to deter unauthorised access to the pressure regulation device.
- 4 Under no circumstances should the set pressure of the safety valve be altered to a different pressure than that stamped on the valve without the permission of the installation designer.
- 5 If the set pressure must be altered then use only correct parts supplied by Atlas Copco and in accordance with the instructions available for the valve type.
- 6 Safety valves must be frequently tested and regularly maintained.
- 7 The set pressure should be periodically checked for accuracy.
- 8 When fitted, the compressors should be operated at pressures not less than 75% of the set pressure to ensure free and easy movement of internal parts.
- 9 The frequency of tests is influenced by factors such as the severity of the operating environment and aggressiveness of the pressurised medium.
- 10 Soft seals and springs should be replaced as part of the maintenance procedure.
- 11 Do not paint or coat the installed safety valve.

Leading particulars

DESCRIPTION OF SAFETY PICTOGRAMS USED IN THIS MANUAL




This symbol draws your attention to dangerous situations. The operation concerned may endanger persons and cause injuries.



This symbol is followed by supplementary information.

GENERAL DESCRIPTION



The compressors type XAHS 146 Dd, XATS 156 Dd, XA(S) 186 Dd, XAVS 166 Dd and XAHS 186 Dd are silenced, single-stage, oil-injected screw compressors, built for a nominal effective working pressure, ranging from 7 bar (102 psi) up to 12 bar (175 psi) (see chapter **Technical specifications**).

Engine

The compressors are driven by a liquid-cooled diesel engine.

The engine's power is transmitted to the compressor through a heavy-duty coupling.

Compressor

The compressor casing houses two screw-type rotors, mounted on ball and roller bearings. The male rotor, driven by the engine, drives the female rotor. The element delivers pulsation-free air.

Injected oil is used for sealing, cooling and lubricating purposes.

Compressor oil system

The oil is boosted by air pressure. The system has no oil pump.

The oil is removed from the air, in the air/oil vessel at first by centrifugal force, secondly by the oil separator element.

The vessel is provided with an oil level indicator.

Regulation

The compressor is provided with a continuous regulating system and a blow-down valve which is integrated in the unloader assembly. The valve is closed during operation by air receiver pressure and opens by air receiver pressure via the compressor element when the compressor is stopped.

When the air consumption increases, the air receiver pressure will decrease and vice versa.

This receiver pressure variation is sensed by the regulating valve which, by means of control air to the unloader and engine speed regulator, matches the air output to the air consumption. The air receiver pressure is maintained between the pre-selected working pressure and the corresponding unloading pressure.

Cooling system

The engine is equipped with a liquid cooler and intercooler. All compressors are equipped with an oil cooler.

The cooling air is generated by a fan, driven by the engine.

Safety devices

A thermal shut-down switch protects the compressor against overheating. The air receiver is provided with a safety valve.

The engine is equipped with low oil pressure and high oil temperature shut-down switches.

Frame and axle

The compressor/engine unit is supported by rubber buffers in the frame.

The standard unit has a non-adjustable towbar with a towing eye.

As an option the unit can be equipped with an adjustable towbar, an overrun and parking brake and towing eyes type DIN, ball, ITA, GB, NATO, AC (France), (see chapter **Available options**).

The braking system consists of an integrated parking brake and overrunbrake. When driving backwards the overrunbrake is not engaged automatically.

Bodywork

The bodywork has openings at the shaped front and rear end for the intake and outlet of cooling air and hinged door for maintenance and service operations. The bodywork is internally lined with sound-absorbing material.

Lifting eye

A lifting eye is accessible when the small door at the top of the unit is unlocked.

Control panel

The control panel grouping the air pressure gauge, control switch etc., is placed in the center at the rear end.


Data plate

The compressor is furnished with a data plate showing the product code, the unit number and the working pressure (see chapter **Data plate**).

Serial number

The serial number is located on the right-hand side towards the front on the upper edge of the frame and also on the data plate.


Main Parts



XAHS 146 Dd, XATS 156 Dd and XA(S) 186 Dd with some options

Reference	Name
A	Alternator
AFce	Air Filter (compressor element)
AFe	Air Filter (engine)
AOV	Air Outlet Valves
AR	Air Receiver
BH	Brake Handle
CC	Coolant Cooler
CE	Compressor Element
CLS	Coolant Level Switch
CP	Control Panel
CT	Coolant Tank
DPoc	Drain Plug Oil Cooler
DSe	Engine Oil Level Dipstick
E	Engine
EP	Exhaust Pipe
F	Fan
FCeo	Filler Cap (engine oil)
FCft	Filler Cap (fuel tank)
FCc	Filler Cap (coolant)
FF	Fuel Filter
FFfp	Fuel Prefilter
FLG	Fuel Level Gauge
FPco	Filler Plug (compressor oil)
FT	Fuel Tank

Reference	Name
IC	Intercooler
MPV	Minimum Pressure Valve
OC	Oil Cooler
OFce	Oil Filter (compressor element)
OFe	Oil Filter (engine)
OLG	Oil Level Gauge (compressor element)
RV	Regulating Valve
S	Starting Motor
SL	Support Leg
SN	Serial Number
SV	Safety Valve
TB	Towbar
VIce	Vacuum Indicator (compressor element)
VIe	Vacuum Indicator (engine)
VV	Vacuator Valve




XAVS 166 Dd and XAHS 186 Dd with some options

Reference	Name
A	Alternator
AFce	Air Filter (compressor element)
AFe	Air Filter (engine)
AOV	Air Outlet Valves
AR	Air Receiver
BH	Brake Handle
CC	Coolant Cooler
CE	Compressor Element
CLS	Coolant Level Switch
CP	Control Panel
CT	Coolant Tank
DPoc	Drain Plug Oil Cooler
DSe	Engine Oil Level Dipstick
E	Engine
EP	Exhaust Pipe
F	Fan
FCeo	Filler Cap (engine oil)
FCft	Filler Cap (fuel tank)
FCc	Filler Cap (coolant)
FF	Fuel Filter
FFfp	Fuel Prefilter
FLG	Fuel Level Gauge
FPco	Filler Plug (compressor oil)
FT	Fuel Tank

Reference	Name
IC	Intercooler
MPV	Minimum Pressure Valve
OC	Oil Cooler
OFce	Oil Filter (compressor element)
OFe	Oil Filter (engine)
OLG	Oil Level Gauge (compressor element)
RV	Regulating Valve
S	Starting Motor
SL	Support Leg
SN	Serial Number
SV	Safety Valve
TB	Towbar
VIce	Vacuum Indicator (compressor element)
VIe	Vacuum Indicator (engine)
VV	Vacuator Valve

OVERVIEW (LOAD CONDITION)



Reference	Name
PG	Pressure Gauge
RV	Regulating Valve
SC	Safety Cartridge (option)
SL	Scavenge Line
SR	Speed Regulator
SV	Safety Valve
TS	Temperature Switch
UA	Unloader Assembly
UV	Unloader Valve
VH	Vent Hole
VI	Vacuum Indicator
VV	Vacuator Valve

AIR FLOW

The system comprises:

AF	Air filter
AR/OS	Air receiver/oil separator
CE	Compressor element
UA/UV	Unloader assembly with unloader valve
BDV	Blow-down valve
LV	Loading valve

Air drawn through the airfilter (AFce) into the compressor element (CE) is compressed. At the element outlet, compressed air and oil pass into the air receiver/oil separator (AR/OS).

The check valve (CV) prevents blow-back of compressed air when the compressor is stopped. In the air receiver/oil separator (AR/OS), most of the oil is removed from the air/oil mixture; the remaining oil is removed by the separator element.

The oil collects in the receiver and on the bottom of the separator element.

The air leaves the receiver via a minimum pressure valve (MPV) which prevents the receiver pressure from dropping below the minimum working pressure (specified in section **Limitations**), even when the air outlet valves are open. This ensures adequate oil injection and prevents oil consumption.

A temperature switch (TS) and a working pressure gauge (WPG) are comprised in the system.

A blow-down valve (BDV) is fitted in the unloader assembly to automatically depressurise the air receiver (AR) when the compressor is stopped.

OIL SYSTEM

The system comprises:

AR/OS	Air receiver/oil separator
OC	Oil cooler
OF	Oil filter

The lower part of the air receiver (AR) serves as an oil tank.

Air pressure forces the oil from the air receiver/oil separator (AR/OS) through the oil cooler (OCce) and oil filter (OF) to the compressor element (CE).


The compressor element has an oil gallery in the bottom of its casing. The oil for rotor lubrication, cooling and sealing is injected through holes in the gallery.

Lubrication of the bearings is ensured by oil injected into the bearing housings.

The injected oil, mixed with the compressed air, leaves the compressor element and re-enters the air receiver, where it is separated from the air as described in section **Air flow**. The oil that collects on the bottom of the oil separator element is returned to the system through a scavenging line (SL), which is provided with a flow restrictor (FR).

The oil filter by-pass valve opens when the pressure drop over the filter is above normal because of a clogged filter. The oil then by-passes the filter without being filtered. For this reason, the oil filter must be replaced at regular intervals (see section **Preventive maintenance schedule for the compressor**).

CONTINUOUS REGULATING SYSTEM



The system comprises:

RV	Regulating valve
UA	Unloader assembly
SR	Speed regulator

The compressor is provided with a continuous regulating system. This system is provided with a blow-down valve, which is integrated in the unloader assembly (UA). The valve is closed during operation by air receiver pressure and opens by air receiver pressure via the compressor element when the compressor is stopped.

When the air consumption increases, the air receiver pressure will decrease and vice versa. This receiver pressure variation is sensed by the regulating valve which, by means of control air to the unloader, matches the air output to the air consumption. The air receiver pressure is maintained between the pre-selected working pressure and the corresponding unloading pressure.

When starting the compressor, the unloader valve (UV) is kept open by spring force, the engine runs at maximum speed. The compressor element (CE) takes in air and pressure builds up inside the receiver (AR).

The air output is controlled from maximum output (100%) to no output (0%) by:

1. Speed control of the engine between maximum load speed and unloading speed (the output of a screw compressor is proportional to the rotating speed).
2. Air inlet throttling.
3. Blow off valve (BOV).

If the air consumption is equal to or exceeds the maximum air output, the engine speed is held at maximum load speed and the unloading valve is fully open.

If the air consumption is less than the maximum air output, the regulating valve supplies control air to unloader valve (UV) to reduce the air output and holds air receiver pressure between the normal working pressure and the corresponding unloading pressure at approx. 1.5 bar (22 psi) above the normal working pressure.

When the air consumption is resumed, the blow off valve (BOV) closes and the unloader valve (UV) gradually opens the air intake and the speed regulator (SR) increases the engine speed.


The construction of the regulating valve (RV) is such that any increase (decrease) of the air receiver pressure above the pre-set valve opening pressure results in a proportional increase (decrease) of the control pressure to the unloading valve and the speed regulator.

Part of the control air is vented into the atmosphere, and any condensate discharged, through the vent holes (VH).

ELECTRICAL SYSTEM

All compressors are equipped with a negative earthed system.

(9822 0893 12)



Reference	Name
1	To be used with Cold Start Option.
2	To be used with Refinery Equipment.
3	Position of DIP-switches.
B6	Fuel Level Sensor
F1	Circuit Breaker
G1	Battery 12V
G2	Charging Alternator
K0	Starter Solenoid
K5	Auxiliary Starter Relay
K6	Cold Start Relay
K9	Overspeed Relay
M1	Starter Motor
N4	Control Module
N5	Overspeed Control Module
P1	Hourmeter
P2	Glowplug
P3	Fuel Level Gauge
S3	Compressor Temperature Switch
S4	Engine Temperature Switch

Reference	Name
S5	Engine Low Oil Pressure Switch
S7	Overspeed Control Test Switch
S8	Push Button
S9	Coolant Level Switch
X1	Module Connector
Y1	Fuel Stop Solenoid
Y2	Excess Fuel Provider
Y3	Overspeed Solenoid




For correct functioning of the module, the dip switches at the back of the module should be positioned as follows.


DIP SWITCHES FOR XAHS 146 Dd, XATS 156 Dd AND XA(S) 186 Dd

Standard (no coldstart)

With coldstart option




Not used
Preheat-Coldstart
Low fuel level
Low coolant level




DIP SWITCHES FOR XAVS 166 Dd AND XAHS 186 Dd

Standard (no coldstart)














With coldstart option


























Not used
Preheat-Coldstart
Low fuel level
Low coolant level



MARKINGS AND INFORMATION LABELS

	Compressor outlet temperature too high.
	Compressor outlet temperature.
	Compressor outlet pressure.
	Dangerous outlet gases.
	Danger, hot surface.
	Electrocution hazard.
 PAROIL M	Atlas Copco mineral compressor oil.
 PAROIL S	Atlas Copco synthetic compressor oil.
 PAROIL E	Atlas Copco mineral engine oil.
 PAROIL Extra	Atlas Copco synthetic engine oil.
	Manual.
	Read the instruction manual before working on the battery.
	Reset fuse.

	On / off button.
	Hours, time.
	Prohibition to open air valves without connected hoses.
	Compressor loaded.
	Runlamp.
	Airfilter.
	Compressor temperature too high.
	Rotation direction.
	Inlet.
	Outlet.
	Compressor oil drain.
	Read the instruction manual before starting.

	Service every 24 hours.
	Warning! Part under pressure.
	Do not stand on outlet valves.
	Start-Stop indication of switch.
	Do not run the compressor with open doors.
	Lifting permitted.
	Use diesel fuel only.
4.75 bar (69 psi)	Tyre pressure.
	Sound power level in accordance with Directive 2000/14/EC (expressed in dB (A)).
	Sound power level in accordance with Directive 2000/14/EC (expressed in dB (A)).
	Sound power level in accordance with Directive 2000/14/EC (expressed in dB (A)).
	Horizontal towbar position required in case of coupling.

Operating instructions

PARKING, TOWING AND LIFTING INSTRUCTIONS

Safety precautions



Never load the vehicles in excess of the permissible total weight.

Never overstress the coupling or suspension system due to reckless or aggressive driving or mishandling. Avoid subjecting the axles to any impacts or jolting. Adapt your driving speed at all times to the road conditions.

Ensure that wheels and tyres are not misaligned or out-of-balance.

Only use the jacking points indicated by Atlas Copco.

The operator is expected to apply all relevant safety precautions, including those mentioned on the pages 7 - 13 of this book.

Attention:




Before putting the compressor into use, check the brake system as described in section Brake (= option) adjustment.

After the first 100 km travel - Yearly or every 5000 km:


Check and retighten the wheel nuts and towbar bolts to the specified torque. See section Height adjustment and section Torque values.

Check the brake adjustment. See section Brake (= option) adjustment.


PARKING INSTRUCTIONS



Non-adjustable towbar with standard support leg without brakes



Adjustable towbar with jockey wheel and brakes



Parking position of jockey wheel




It must be noted that, with the parking brake activated, the vehicle can roll back about 30 cm until the braking force takes full effect.


When parking a compressor, secure support leg (1) or jockey wheel (2) to support the compressor in a level position. Be sure that the jockey wheel (2) is blocked by the blocking pin (4).

Apply parking brake by pulling parking brake handle (3) upwards. Place the compressor as level as possible; however, it can be operated temporarily in an out-of-level position not exceeding 15°. If the compressor is parked on sloping ground, immobilize the compressor by placing wheel chocks (available as option) in front of or behind the wheels.

TOWING INSTRUCTIONS





Locate the rear-end of the compressor upwind, away from contaminated wind-streams and walls. Avoid recirculation of exhaust air from the engine. This causes overheating and engine power decrease.



Label on towbar

Inspections, prior to each run

- Check tyre pressure and tyre condition
- Check wheel fixation
- Check screwed joints on firm seating.
- Check functioning of lighting and braking systems (option)
- The jockey wheel must be parallel to the direction of travel at all times.
- Inspect the coupling. The ball joint must fully enclose the ball and be locked.
- At height adjustable towing facility (option), check the joint connection for a tight fit.






Before towing the compressor, ensure that the towing equipment of the vehicle matches the towing eye or ball connector and ensure that the service doors are closed and locked properly.

For both non-adjustable - and adjustable towbar, the towbar should be as level as possible and the compressor and towing eye end in a level position.

Push the hand brake lever (1) completely downwards and connect breakaway cable (2) to the vehicle. Secure jockey wheel (3) or support leg in the highest possible position (see figure). The jockey wheel is prevented from turning.

HEIGHT ADJUSTMENT (with adjustable towbar)



Before towing the compressor, make sure that the joints of the towbar are secured with maximum strength without damaging the towbar. Be sure that there is no clearance between the teeth of the joints.

- Remove spring pin (1).
- Release locking nut (2) with support tools (Extension tube 3).
- Adjust required height of the towbar.
- Tighten locking nut (2) by hand first.
- Secondly tighten locking nut (2) with a tightening torque corresponding to table. With an extension tube (3) ("A" corresponding to table) and handforce ("B" corresponding to table) easy tightening is possible.
- Fix locking nut (2) with spring pin (1).




Attention:

- Height adjustment should be undertaken on levelled ground and in coupled condition.
- When readjusting, make sure that the front point of the towbar is horizontal with the coupling point.
- Before starting a trip, ensure that the adjustment shaft is secure, so that stability and safety is guaranteed while driving. If necessary, tighten the locking nut (2) corresponding with table.

For specific instruction see below!

Type	M [Nm/lbf.ft.]	"A" [mm/in]	"B" [N/lbf]
ZV 2000	250 - 300 / 184.5 - 221.4	600 / 23.4	420 - 500 / 94.5 - 112.5
ZV 2500	350 - 400 / 258.3 - 295.2	600 / 23.4	580 - 660 / 130.5 - 148.5

INSTRUCTIONS BALL COUPLING (OPTION)



The handle of the ball coupling and the handbrake lever may never be used as a manoeuvring aid; internal components may get damaged!

The coupling (ball coupling) on the tow bar is type approved. The maximum load at the coupling may not be exceeded.

When coupling lower the jockey wheel to the ground. Reverse the car up to the compressor or, in the case of a small compressor, manoeuvre the compressor up to the car's trailer coupling.

Coupling:

Open coupling jaw by pulling the lever vigorously upwards in the direction of the arrow. Lower the opened coupling onto the ball of the vehicle coupling and the lever will automatically be lowered. Closing and locking are carried out automatically. Check the "+" (see figure) position!

Connect the breakaway cable and electrical plug (option) to the towing vehicle. Raise the jockey wheel up fully and secure by firmly clamping it. Release parking brake before setting off.


Visual check: the ball should no longer be visible in coupled condition.

Uncoupling:

Lower the jockey wheel. Disconnect breakaway cable and electrical plug. Pull the lever vigorously upwards in the direction of the arrow and hold. Wind down jockey wheel (option) and lift the compressor off the ball of the towing vehicle.

Secure the compressor by means of a wheel chock and/or by applying the parking brake.

LIFTING INSTRUCTIONS



When lifting the compressor, the hoist has to be placed in such a way that the compressor, which must be placed level, is lifted vertically. Keep lifting acceleration and retardation within safe limits.

Preferably use the lifting eye (1) herefore open the small door (2).



Lifting acceleration and retardation must be kept within safe limits (max. 2g).


Helicopter lifting is not allowed.

Lifting is not allowed when the unit is running.

STARTING/STOPPING


BEFORE STARTING

- 1. Before initial start-up, prepare battery for operation if not already done. See section **Battery care**.
- 2. With the compressor standing level, check the level of the engine oil. Add oil, if necessary, up to the upper mark on the dipstick. Consult the Engine Operation Manual for the type and viscosity grade of the engine oil.
- 3. Check the level of the compressor oil. See section **Compressor regulating system**. The pointer of the oil level gauge (OLG) should register in the green range. Add oil if necessary. See section **Oil specifications** for the oil to be used.

 **Before removing the oil filler plug (FP), ensure that the pressure is released by opening an air outlet valve.**

- 4. Check that the fuel tank contains sufficient fuel. Top up, if necessary. Consult the Engine Operation Manual for the type of fuel.
- 5. Drain any water and sediment from the fuel filter until clean fuel flows from the drain cock.
- 6. Press vacuator valves (VV) of the air filters to remove dust.
- 7. Check the air filter vacuum indicators (VI). If the yellow piston reaches the red marked service range, replace the filter element. Reset the indicator by pushing the reset button.
- 8. Open air outlet valve to allow air flow to the atmosphere.

CONTROL PANEL



P1	Hourmeter	
F1	Circuit Breaker Button	
PG	Working pressure gauge	
LV	Loading Valve	
N4	Control Module	
S	Start/Stop Button	
H1	LED (green)	Fuel ON
H2	LED (green)	Preheat (option)
H3	LED (red)	Charge Indication
H4	LED (red)	Compressor Outlet Temperature
H5	LED (red)	Engine Oil Temperature
H6	LED (red)	Engine Oil Pressure
H7	LED (red)	Low Coolant
H8	LED (red)	Low Fuel



Never push the start button when the engine is running.

Make sure the fuel tank is filled up.

Before starting, first operate the circuit breaker button (F1) at the right side of the control panel (open right-hand service door first).

To start, the start/stop button (S) is switched to position "I", the green fuel ON lamp (H1), the red charge indication lamp (H3) and preheat lamp (H2) go on (preheat lamp only, if "cold start" option is installed). After preheating, the preheat lamp goes out. Push the start/stop button in position "I" (1). 20 sec. (60 sec. for XAHS 186 Dd) cranking, 1 min. rest (= a cycle). Max. 3 cycles are allowed. The starter motor will set the engine in motion. Lamps H1 and H3 will go out as soon as the engine has been started. After the start/stop button is released, it automatically springs back to position "I".

Run the engine a few minutes at no-load to warm up.

When the engine is running smoothly, press loading valve (LV) and release as soon as pressure starts to build up.

Shutting down is simply done by pushing the start button in the "0" position.

The control panel in addition indicates receiver pressure (PG) and accumulated operating hours (P1).

Fault situations and protective devices (Also refer to chapter Problem solving):

- The starter motor is protected against prolonged starting.
(max. cranking time: 20 sec. (60 sec. for XAHS 186 Dd)).
- A fault which occurs with the engine, either alternator voltage (too low), coolant temperature too high, oil pressure too low or fuel level too low will always and immediately cause the engine to cut out and one of the control lamps H3, H5, H6, H7 or H8 to light up.
- When the outlet temperature of the element becomes too high, a thermocontact will also switch off the unit immediately.
Control lamp H4 will light up.
- The control lamps will remain on until the unit has been reset (start button switched to position "0").

DURING OPERATION



When the engine is running, the air outlet valves (ball valves) must always be in a fully opened or fully closed position.

Regularly carry out following checks:

1. That regulating valve (see section **Main Parts**, RV) is correctly adjusted, i.e. starts decreasing the engine speed when reaching the preset working pressure in the receiver.
2. Check the air filter vacuum indicators (see section **Main Parts**, VI). If the yellow piston reaches the red marked service range, replace the filter element. Reset the indicators by pushing the reset button.



The doors must be closed during operation and may be opened for short periods only.

Maintenance

USE OF SERVICE PAKS

Service Paks include all genuine parts needed for normal maintenance of both compressor and engine.

Service Paks minimize downtime and keep your maintenance budget low.

Order Service Paks at your local Atlas Copco dealer.

PREVENTIVE MAINTENANCE SCHEDULE FOR THE COMPRESSOR

The schedule contains a summary of the maintenance instructions. Read the respective section before taking maintenance measures.

When servicing, replace all disengaged packings, e.g. gaskets, O-rings, washers.

For engine maintenance refer to Engine Operation Manual.

The maintenance schedule has to be seen as a guideline for units operating in a dusty environment typical for compressor applications. Maintenance schedule can be adapted depending on application environment and quality of maintenance.

<i>To determine the maintenance intervals, use service hours, or calendar time, whichever occurs first.</i>						
Maintenance schedule (running hrs)	Daily	50 hrs after initial start-up	Every 500 hrs	Every 1000 hrs	Every 2000 hrs	Yearly
Service Paks						
XAHS 146 Dd - XAHS 300 DD6 Deutz TCD			2912 4499 05	2912 4501 06		
XATS 156 Dd - XATS 350 DD6 Deutz TCD XA(S) 186 Dd - XA(S) 375 DD6 Deutz TCD			2912 4499 05	2912 4502 06		
XATS 156 Dd - XATS 350 DD6 Deutz BF4M XA(S) 186 Dd - XA(S) 375 DD6 Deutz BF4M			2912 4306 05	2912 4337 06		
XAVS 166 Dd - XAVS 340 DD6 Deutz TCD XAHS 186 Dd - XAHS 375 DD6 Deutz TCD			2912 4500 05	2912 4503 06		
Oil Separator Kit				2911 0075 00		
<i>For the most important subassemblies, Atlas Copco has developed service kits that combine all wear parts. These service kits offer you the benefits of genuine parts, save administration costs and are offered at a reduced price, compared to individual components. Refer to the parts list for more information on the contents of the service kits.</i>						
Drain water from fuel filter	x					
Empty air filter vacuator valves	x					
Check engine oil level (if necessary top up)	x					
Check compressor oil level (if necessary top up)	x					

(to be continued on page 34)

Maintenance schedule (running hrs) <i>(continuation of page 33)</i>	Daily	50 hrs after initial start-up	Every 500 hrs	Every 1000 hrs	Every 2000 hrs	Yearly
Check coolant level	x					
Check/Fill fuel level (3)	x					
Check control panel	x					
Check on abnormal noise	x					
Check electrical system cables for wear			x	x	x	x
Check for leaks in engine-, compressor-, air-, oil-, or fuel system		x	x	x	x	x
Check torque on critical bolt connections		x	x	x	x	x
Check electrolyte level and terminals of battery		x	x	x	x	x
Check engine (minimum and maximum) speed		x	x	x	x	x
Hoses and clamps - Inspect/Replace		x	x	x	x	
Drain/Clean fuel tank water and sediments (1)			x	x	x	x
Check air intake vacuum indicators (1)			x	x	x	x
Change engine oil (2)			x	x	x	x
Replace engine oil filter (2)			x	x	x	x
Replace fuel (pre)filters (6)			x	x	x	x
Clean flow restrictor in oil scavenge line			x	x	x	x
Adjust engine inlet and outlet valves (2)			x	x	x	
Check/Test glow plugs - grid heater			x	x	x	x
Clean after cooler (option) (1)			x	x	x	x
Clean oil cooler(s) (1)			x	x	x	x
Clean radiator (1)			x	x	x	x
Clean intercooler (1)			x	x	x	x
Check functioning of regulating valve				x	x	x
Replace compressor oil filter(s) (5)				x	x	x
Test safety valve (9)				x	x	x

(to be continued on page 35)

Maintenance schedule (running hrs) <i>(continuation of page 34)</i>	Daily	50 hrs after initial start-up	Every 500 hrs	Every 1000 hrs	Every 2000 hrs	Yearly
Replace bleed-off valve unloader				x	x	x
Check rubber flexibles (10)				x	x	x
Replace DD/PD/QD filter (option)				x	x	x
Change compressor oil (1) (7)				x	x	x
Replace oil separator element				x	x	x
Replace air filter element (1)				x	x	x
Inspection by Atlas Copco service technician				x	x	x
Grease hinges						x
Check emergency stop						x
Analyse coolant (4) (8)						x
Check/Replace safety cartridge						x
Inspect starter motor						x
Inspect turbocharger						x
Inspect waterpump						x
Inspect alternator						x

(to be continued on page 36)

Notes

(continuation of page 35)



1. More frequently when operating in a dusty environment.
2. Refer to engine operation manual.
3. After a days work.
4. Yearly is only valid when using PARCOOL. Change coolant every 5 years.
5. Use Atlas Copco oil filters, with by-pass valve as specified in the parts list.
6. Gummed or clogged filters means fuel starvation and reduced engine performance.
7. See section **Oil specifications**.
8. The following part numbers can be ordered from Atlas Copco to check on inhibitors and freezing points:
 - 2913 0028 00 refractometer
 - 2913 0029 00 pH meter
9. See section **Safety valve**.
10. Replace all rubber flexibles every 6 years.
For other specific engine and alternator requirements refer to specific manuals.



Keep the bolts of the housing, the lifting beam, tow bar and axles securely tightened. For torque values see section Technical specifications.

Maintenance schedule (km)	Daily	50 km after initial start-up	Every 500 km	Every 2000 km	Yearly
<i>To determine the maintenance intervals, use mileage indication in km or calender time, whichever occurs first.</i>					
Check towbar, handbrake lever, spring actuator, reversing lever, linkage and all movable parts for ease of movement	x	x	x	x	x
Check height of adjusting facility	x				x
Check coupling head	x			x	x
Check tyre pressure		x	x	x	x
Oil or grease brake lever and moving parts such as bolts and joints		x		x	x
Grease coupling head, towbar bearings at the housing of the overrun brake		x		x	x
Check torque of wheel nuts		x		x	x
Check brake system (if installed) and adjust if necessary		x		x	x
Lubricate torsion bar axle trailing arm				x	x
Grease sliding points on height adjusting parts				x	x
Check tyres for uneven wear				x	x
Check safety cable for damage				x	x
Check hub cap for firm seating				x	x
Check Bowden cable on height adjustable connection device for damage				x	x
Check/adjust lateral play of wheel bearing (compact bearing)					x
Check brake lining wear					x

OIL SPECIFICATIONS



It is strongly recommended to use Atlas Copco branded lubrication oils for both compressor and engine. If you want to use another brand of oil, consult Atlas Copco.

High-quality, mineral, hydraulic or synthesized hydrocarbon oil with rust and oxidation inhibitors and anti-foam and anti-wear properties is recommended. The viscosity grade should correspond to the ambient temperature and ISO 3448, as follows:



Never mix synthetic with mineral oil.

Remark:

When changing from mineral to synthetic oil (or the other way around), you will need to do an extra rinse:

After a complete change over to synthetic oil, run the unit for a few minutes to allow proper and complete circulation of the synthetic oil.

Then drain the synthetic oil again and fill again with new synthetic oil. To set correct oil levels, follow the normal instructions.

PAROIL from Atlas Copco is the **ONLY** oil tested and approved for use in all engines built into Atlas Copco compressors and generators.

Extensive laboratory and field endurance tests on Atlas Copco equipment have proven PAROIL to match all lubrication demands in varied conditions. It meets stringent quality control specifications to ensure your equipment will run smoothly and reliably.

The quality lubricant additives in PAROIL allow for extended oil change intervals without any loss in performance or longevity.

PAROIL provides wear protection under extreme conditions. Powerful oxidation resistance, high chemical stability and rust-inhibiting additives help reduce corrosion, even within engines left idle for extended periods.

PAROIL contains high quality anti-oxidants to control deposits, sludge and contaminants that tend to build up under very high temperatures.

PAROIL's detergent additives keep sludge forming particles in a fine suspension, instead of allowing them to clog your filter and accumulate in the valve/rocker cover area.

PAROIL releases excess heat efficiently, whilst maintaining excellent bore-polish protection to limit oil consumption.

PAROIL has an excellent Total Base Number (TBN) retention and more alkalinity to control acid formation.


PAROIL prevents Soot build-up.

PAROIL is optimized for the latest low emission EURO -3 & -2, EPA TIER II & III engines running on low sulphur diesel for lower oil and fuel consumption.

PAROIL E is a mineral based high performance diesel engine oil with a high viscosity-index. Atlas Copco PAROIL E is designed to provide a high level of performance and protection under 'standard' ambient conditions from -10°C (14°F) onward.

PAROIL E xtra is a Synthetic ultra high performance diesel engine oil with a high viscosity-index. Atlas Copco PAROIL E xtra is designed to provide excellent lubrication from start-up at temperatures as low as -25°C (-13°F).

COMPRESSOR OIL



Choose your compressor oil based on the ambient temperatures in the actual operating area.

Mineral compressor oil PAROIL M

	Liter	US gal	Order number
can	5	1.3	1615 5947 00
can	20	5.3	1615 5948 00
barrel	209	55.2	1615 5949 00

Synthetic compressor oil PAROIL S

	Liter	US gal	Order number
can	5	1.3	1630 0160 00
can	20	5.3	1630 0161 00
barrel	209	55.2	1630 0162 00
container	1000	265	1630 0163 00


Mineral engine oil PAROIL E

	Liter	US gal	Order number
can	5	1.3	1615 5953 00
can	20	5.3	1615 5954 00
barrel	209	55.2	1615 5955 00

Synthetic engine oil PAROIL E xtra


	Liter	US gal	Order number
can	5	1.3	1630 0135 01
can	20	5.3	1630 0136 01
barrel	209	55.2	1626 0102 00

ENGINE OIL



Choose your engine oil based on the ambient temperatures in the actual operating area.

COMPRESSOR OIL LEVEL CHECK



DAILY CHECK

Check the compressor oil level daily, after running the compressor.



The compressor oil level needs to be checked with the compressor in an horizontal position after running the compressor to warm up so that the thermostatic valve is open.

1. Stop the compressor with closed air outlet valve (3) and let it rest for a short period, to allow the system to relief pressure inside the vessel and settle down the oil.
2. Depending on the level indicator, check the oil level via:
 - the pointer of the oil level gauge (1). The pointer must register in the green area.
 - the oil filler plug. The level must be between the two markings as indicated in the label on the oil vessel.
3. If the oil level is too low, add oil via the oil filler plug (2)



Before removing the oil filler plug, ensure that the pressure is released by opening the air outlet valve (3) and checking the vessel pressure on the controller or the pressure gauge.

4. Top up with oil until:
 - the pointer of the oil level gauge is in the upper part of the green area
 - the oil level is at the upper level as indicated on the label
5. Reinstall and tighten the filler plug.

CHECK AFTER A LONGER PERIOD WITHOUT RUNNING THE COMPRESSOR

1. Depending on the level indicator, check the oil level via:
 - the pointer of the oil level gauge (1). The pointer must register in the green area.
 - the oil filler plug. The level must be between the two markings as indicated in the label on the oil vessel.
2. If the oil level is too low, remove the oil filler plug (2) and check if there is still oil in the vessel
 - No oil in the vessel: Top up the compressor with oil until the pointer of the oil level gauge is in the upper part of the green area or the oil level is at the upper level as indicated on the label and follow the steps as described above in **Daily check**.
 - Oil in the vessel: Start up the unit to warm up and give time for the thermostatic valve to open. Stop the compressor with closed outlet valve (3) and follow the steps described above in **Daily check**.



At temperatures below 0°C, you have to load the compressor to be sure that the compressor thermostat will be open.

ENGINE OIL

ENGINE OIL LEVEL CHECK



Never mix oils of different brands or types.

Use only non-toxic oils where there is a risk of inhaling delivered air.

Consult the Engine Operation Manual for oil specifications and viscosity recommendations.


For intervals, see **Preventive maintenance schedule for the compressor.**

Check engine oil level in accordance to the instructions in the Engine Operation Manual and if necessary, top up with oil.

ENGINE OIL AND OIL FILTER CHANGE

See section **Preventive maintenance schedule for the compressor.**

COMPRESSOR OIL AND OIL FILTER CHANGE



The quality and the temperature of the oil determine the oil change interval.

The prescribed interval is based on normal operating conditions and an oil temperature of up to 100 °C (212 °F) (see section **Preventive maintenance schedule for the compressor**).

When operating in high ambient temperatures, in very dusty or high humidity conditions, it is recommended to change the oil more frequently.



In this case, contact Atlas Copco.

1. Run the compressor until warm. Close the outlet valve(s) (1) and stop the compressor. Wait until the pressure is released through the automatic blow-down valve. Unscrew the oil filler plug (2) by a single turn. This uncovers a vent hole, which permits any pressure in the system to escape.

2. Drain the compressor oil by removing all relevant drain plugs. Drain plugs are fitted at the air receiver (DPar), compressor element (DPcv, DPosv) and compressor oil cooler (DPoc). Catch the oil in a drain pan. Unscrew the filler plug (2) to speed up draining. After draining, reposition and tighten the drain plugs.
3. Remove the oil filters (3), e.g. by means of a special tool. Catch the oil in a drain pan.
4. Clean the filter seat on the manifold, taking care that no dirt drops into the system. Oil the gasket of the new filter element. Screw it into place until the gasket contacts its seat, then tighten one half turn only.
5. Fill the air receiver until the pointer of the oil level gauge is in the upper part of the green area. Be sure that no dirt gets into the system. Reinstall and tighten the filler plug (2).
6. Start the compressor and let it run unloaded for a few minutes.
7. Stop the compressor, wait a few minutes and top up with oil until the pointer of the oil level gauge is in the upper part of the green area.



Never add more oil. Overfilling results in oil consumption.

COMPRESSOR OIL FLUSHING PROCEDURE



Not respecting compressor oil changing intervals in accordance with the maintenance schedule, can lead to serious problems, including fire hazard! The manufacturer does not accept any liability for damage arising from not following the maintenance schedule or not using genuine parts.

To avoid problems when changing over to a new type of oil (see table) a special Compressor Oil Flushing Procedure has to be followed. The procedure is only valid in case the replaced oil has not exceeded its lifetime. For more information consult Atlas Copco Service dept.

Aged oil can be recognized best by using an oil sampling analysis program. Indicators for aged oil are strong smell, or contamination such as sludge and varnish inside the oil vessel and oil stop valve or a brownish colour of the oil.

Whenever aged oil is discovered, eg. when changing the oil separator, contact Atlas Copco Service dept. to have your compressor cleaned and flushed.

1. First thoroughly drain the system when the oil is warm, leaving as little oil in the system as possible, especially in dead areas, if possible blow out remaining oil by pressurising the oil system. Check the instruction manual for detailed description.
2. Remove the compressor oil filter(s).
3. Open the oil vessel and remove the oil separator element.



Instructions on replacing the oil separator element are available from Atlas Copco Service dept.

4. Check the interior of the oil vessel (see pictures). If varnish deposits are discovered, contact Atlas Copco Service dept. and do not continue.
5. Put in a new oil separator, screw on new compressor oil filter(s) and close the oil vessel according to the instructions.
6. Fill the oil vessel with the minimum amount of replacement oil, run the compressor under light load conditions for 30 minutes.
7. Thoroughly drain the system when the oil is warm, leaving as little oil in the system as possible, especially in dead areas, if possible blow out remaining oil by pressurising the oil.
8. Fill the system with the final oil charge.
9. Run the compressor under light load conditions for 15 minutes and check for leakage.
10. Check the oil level and top up if necessary.
11. Collect all waste lubricant used during the flushing process and dispose of it in accordance with the applicable procedures for managing waste lubricant.



*Vessel cover
contaminated*

clean



*Vessel
contaminated*

clean

	PAROIL M	PAROIL S
PAROIL M	draining *	flushing
PAROIL S	draining **	draining *

* When changing over to the same oil within the oil changing interval, draining is sufficient

** Change over not recommended

COOLANT SPECIFICATIONS



Never remove the cooling system filler cap while coolant is hot.

The system may be under pressure. Remove the cap slowly and only when coolant is at ambient temperature. A sudden release of pressure from a heated cooling system can result in personal injury from the splash of hot coolant.



It is strongly recommended to use Atlas Copco branded coolant.

The use of the correct coolant is important for proper heat transfer and protection of liquid-cooled engines. Coolants used in these engines must be mixtures of good quality water (distilled or de-ionised), special coolant additives and anti-freeze, if required. Coolant that is not to manufacturer's specification will result in mechanical damage of the engine.

The freezing point of the coolant must be lower than the freezing point that can occur in the area. The difference must be at least 5°C (9°F). If the coolant freezes, it may crack the cylinder block, radiator or coolant pump.

Consult the engine's operation manual and follow the manufacturer's directions.



Never mix different coolants and mix the coolant components outside the cooling system.

PARCOOL EG

PARCOOL EG is the only coolant that has been tested and approved by all manufacturers of engines currently used in Atlas Copco compressors and generators.

Atlas Copco's PARCOOL EG extended life coolant is the new range of organic coolants purpose-designed to meet the needs of modern engines. PARCOOL EG can help prevent leaks caused by corrosion. PARCOOL EG is also fully compatible with all sealants and gasket types developed to join different materials used within an engine.

PARCOOL EG is a ready to use Ethylene Glycol based coolant, premixed in an optimum 50/50 dilution ratio, for antifreeze protection guaranteed to -40°C (-40°F).

PARCOOL EG

	Liter	US gal	Order number
can	5	1.3	1604 5308 01
can	20	5.3	1604 5307 02
barrel	210	55.2	1604 5306 01

To ensure protection against corrosion, cavitation and formation of deposits, the concentration of the additives in the coolant must be kept to certain limits, as stated by the manufacturer's guidelines. Topping up the coolant with water only, changes the concentration and is therefore not allowed.

Liquid-cooled engines are factory-filled with this type of coolant mixture.

PARCOOL EG Concentrate

	Liter	US gal	Order number
can	5	1.3	1604 8159 01

Because PARCOOL EG inhibits corrosion, deposit formation is minimized. This effectively eliminates flow restriction problems through the engine coolant ducts and the radiator, minimizing the risk of engine overheating and possible failure.

It reduces water pump seal wear and has excellent stability when subjected to sustained high operating temperatures.

PARCOOL EG is free of nitride and amines to protect your health and the environment. Longer service life reduces the amount of coolant produced and disposal requirements, which limits environmental impact.

HANDLING PARCOOL EG

PARCOOL EG should be stored at ambient temperatures, while periods of exposure to temperatures above 35°C (95°F) should be minimized. PARCOOL EG can be stored for a minimum of 5 years in unopened containers without any effect on the product quality of performance.

PARCOOL EG is compatible with most other coolants based on ethylene glycol, but you only get the benefits of 5 years protection when its used on its own. Exclusive use of PARCOOL EG is recommended for optimum corrosion protection and sludge control.

For simple density-measuring of Ethylene Glycol and Propylene Glycol in general the standard available 'density' measuring devices are used to measure the concentration of EG. In case a device is used to measure EG, no PG can be measured afterwards as a result of the difference in the density. More specific measurements can be done by the use of a refractometer. This device can measure both EG and PG. A mix of both products will be show unreliable results!

Mixed EG coolants with identical glycol type can be measured by use of a refractometer as well as the 'density' system. The mixed coolants will be considered as one product.

The use of distilled water is recommended. If you have exceptionally soft water it would be acceptable, as well. Basically, the engine metals are going to corrode to some extent no matter what water you use, and hard water will encourage the resulting metal salts to precipitate.

PARCOOL EG comes as a pre-mixed coolant to safeguard the quality of the complete product.

It is recommended that topping up of the cooling system is always done with PARCOOL EG.

COOLANT CHECK



Never remove the cooling system filler cap while coolant is hot.

The system may be under pressure. Remove the cap slowly and only when coolant is at ambient temperature. A sudden release of pressure from a heated cooling system can result in personal injury from the splash of hot coolant.

In order to guarantee the lifetime and quality of the product, thus optimising engine protection, regular coolant-condition-analysis is recommended.

The quality of the product can be determined by three parameters:

Visual check

- Verify the appearance of the coolant with regard to its colour and make sure that no loose particles are floating around.

pH measurement

- Check the pH value of the coolant using a pH-measuring device.
- The pH-meter can be ordered from Atlas Copco with part number 2913 0029 00.
- Typical value for EG = 8.6.
- If the pH-level is below 7 or above 9.5, the coolant should be replaced.

Glycol concentration measurement

- To optimise the unique engine protection features of the PARCOOL EG, the concentration of the Glycol in the water should always be above 33 vol.%.
- Mixtures exceeding a 68 vol.% mix ratio in water are not recommended, as this will lead to high engine operating temperatures.
- A refractometer can be ordered from Atlas Copco with part number 2913 0028 00.



In case of a mix of different coolant products this type of measuring might provide incorrect values.

TOPPING UP/REPLACING COOLANT

- Verify whether the engine cooling system is in a good condition (no leaks, clean,...).
- Check the condition of the coolant.
- If the condition of the coolant is no longer up to standard, the complete coolant should be replaced (see section **Replacing the coolant**).
- Always top-up with PARCOOL EG Concentrate / PARCOOL EG.
- Topping up the coolant with water only, changes the concentration of additives and is therefore not allowed.

TOPPING UP WITHOUT DRAINING FROM THE COOLING SYSTEM

The quantity of PARCOOL EG Concentrate to be topped up can be estimated with the following formula and/or graph:


Corrections concentrate in measured system towards 50% volume by using PARCOOL EG Concentrate

PN: 1604 8159 01

Example:

Total volume coolant = 14 Liter
Measured concentration = 33 Vol %
 $50 - \frac{33}{33} = \frac{17}{17} * \frac{14}{50} = 4,8$ Liter PARCOOL EG Concentrate

Top-up volume PARCOOL EG Concentrate without drainage



In case of expansion tank at low level, this quantity is to be filled without draining from the cooling system.

- 1 Refractometer indication -20° C (-4° F) (33%)
- 2 Refractometer indication -22° C (-7.6° F)
- 3 Refractometer indication -25° C (-13° F)
- 4 Refractometer indication -30° C (-22° F)
- 5 Refractometer indication -36° C (-32.8° F)

TOPPING UP AFTER LIMITED QUANTITY DRAINING FROM THE COOLING SYSTEM

The quantity of PARCOOL EG Concentrate to be topped up after draining a calculated volume from the cooling system, can be estimated with the following formula and/or graph:


Corrections concentrate in measured system towards 50% volume by using PARCOOL EG Concentrate

PN: 1604 8159 01

Example:

Total volume coolant = 80 Liter
Measured concentration = 33 Vol %
50- 33 = 17 * 80 / 67 = 20 Liter PARCOOL EG Concentrate
100- 33 = 67

Top-up volume PARCOOL EG Concentrate with drainage



In case of expansion tank at normal level, this quantity is to be drained from the cooling system.

- 1 Refractometer indication -20° C (-4° F) (33%)
- 2 Refractometer indication -22° C (-7.6° F)
- 3 Refractometer indication -25° C (-13° F)
- 4 Refractometer indication -30° C (-22° F)
- 5 Refractometer indication -36° C (-32.8° F)

REPLACING THE COOLANT

Drain

- Completely drain the entire cooling system.
- Used coolant must be disposed of or recycled in accordance with legislation and local regulations.

Flush

- Flush twice with clean water. Used coolant must be disposed of or recycled in accordance with legislation and local regulations.
- Using the Atlas Copco Instruction book, determine the amount of PARCOOL EG required and pour into the radiator top tank.
- It should be clearly understood that proper cleaning reduces contamination risks.
- In case of "other" coolant residues inside the system, the coolant with the lowest properties influences the quality of the 'mixed' coolant.


Fill

- To assure proper operation and the release of trapped air, run the engine until normal engine operation temperature is reached. Turn off the engine and allow to cool.
- Recheck coolant level and add coolant mixture if necessary.



In case of a mix of different coolant products this type of measuring might provide incorrect values.

CLEANING COOLERS



Keep the coolers clean to maintain the cooling efficiency.



Remove any dirt from the coolers with a fibre brush. Never use a wire brush or metal objects.

Then clean by air jet in reverse direction of normal flow.

Steam cleaning in combination with a cleansing agent may be applied.



To avoid damaging the coolers, angle between jet and coolers should be approx. 90° (do not use jet at max. power).



Protect the electrical and controlling equipment, air filters, etc. against penetration of moisture.

Close the service door(s).



Never leave spilled liquids such as fuel, oil, water and cleansing agents in or around the compressor.



Caution: do not top up when the engine is hot.

BATTERY CARE



Before handling batteries, read the relevant safety precautions and act accordingly.

If the battery is still dry, it must be activated as described in section **Activating a dry-charged battery**.

The battery must be in operation within 2 months from being activated; if not, it needs to be recharged first.

ELECTROLYTE



Read the safety instructions carefully.

Electrolyte in batteries is a sulphuric acid solution in distilled water.

The solution must be made up before being introduced into the battery.



Always pour the sulphuric acid carefully into the distilled water; never pour the water into the acid.

ACTIVATING A DRY-CHARGED BATTERY

- Take out the battery.
- Battery and electrolyte must be at equal temperature above 10°C (50°F).
- Remove cover and/or plug from each cell.
- Fill each cell with electrolyte until the level reaches 10 mm (0.4 in) to 15 mm (0.6 in) above the plates, or to the level marked on the battery.
- Rock the battery a few times so that possible air bubbles can escape; wait 10 minutes and check the level in each cell once more; if required, add electrolyte.
- Refit plugs and/or cover.
- Place the battery in the compressor.

RECHARGING A BATTERY

Before and after charging a battery, always check the electrolyte level in each cell; if required, top up with distilled water only. When charging batteries, each cell must be open, i.e. plugs and/or cover removed.



Use a commercial automatic battery charger according to its manufacturer's instructions.

Apply with preference the slow charging method and adjust the charge current according to the following rule of thumb:

battery capacity in Ah divided by 20 gives safe charging current in Amp.

MAKE-UP DISTILLED WATER

The amount of water evaporating from batteries is largely dependant on the operating conditions, i.e. temperatures, number of starts, running time between start and stop, etc...

If a battery starts to need excessive make-up water, this points to overcharging. Most common causes are high temperatures or a too high voltage regulator setting.

If a battery does not need any make-up water at all over a considerable time of operation, an undercharged battery condition may be caused by poor cable connections or a too low voltage regulator setting.

PERIODIC BATTERY SERVICE

- Keep the battery clean and dry.
- Keep the electrolyte level at 10 to 15 mm above the plates or at the indicated level; top up with distilled water only. Never overfill, as this will cause poor performance and excessive corrosion.
- Record the quantity of distilled water added.
- Keep the terminals and clamps tight, clean, and lightly covered in petroleum jelly.
- Carry out periodic condition tests. Test intervals of 1 to 3 months, depending on climate and operating conditions, are recommended.

If doubtful conditions are noticed or malfunctions arise, keep in mind that the cause may be in the electrical system, e.g. loose terminals, voltage regulator maladjusted, poor performance of compressor, etc...

STORAGE

Run the compressor regularly, e.g. twice a week, until warm.

Load and unload the compressor a few times to operate the unloading and regulating components. Close the air outlet valves after stopping.



If the compressor is going to be stored without running from time to time, protective measures must be taken.

SERVICE PAKS

A Service Pak is a collection of parts to be used for a specific maintenance measure.

It guarantees that all necessary parts are replaced at the same time keeping down time to a minimum.

The order number of the Service Paks are listed in the Atlas Copco Parts List.

SERVICE KITS

A service kit is a collection of parts to fit a specific repair or rebuilding task.

It guarantees that all necessary parts are replaced at the same time which improves the uptime of the unit.

The order numbers of the Service Kits are listed in the Atlas Copco Parts List.



Contact Atlas Copco.

COMPRESSOR ELEMENT OVERHAUL


When a compressor element is due for overhaul, it is recommended to have it done by Atlas Copco. This guarantees the use of genuine parts and correct tools with care and precision.

LIABILITY

The manufacturer does not accept any liability for any damage arising from the use of non-original parts and for modifications, additions or conversions made without the manufacturer's approval in writing.

Adjustments and servicing procedures

ADJUSTMENT OF THE CONTINUOUS REGULATING SYSTEM




The working pressure is determined by the tension of the spring in the regulating valve (1). This tension can be increased to raise the pressure and decreased by turning the adjusting wheel clockwise and anti-clockwise respectively.

		X	Y	Z1 – Z2
XAHS 146 Dd	bar	13.5	12	13.2 – 13.6
	psi	196	174	191.5 – 197.5
XATS 156 Dd	bar	11.8	10.3	11.7 – 12.2
	psi	171	149	167 – 173
XA(S) 186 Dd	bar	8.3	7	8.1 – 8.5
	psi	120.5	101.5	117.5 – 123.5
XAVS 166 Dd	bar	15.5	14	15.3 – 15.7
	psi	225	203	219 – 227
XAHS 186 Dd	bar	13.5	12	13.3 – 13.7
	psi	196	174	191.5 – 197.5

To adjust the normal working pressure, proceed as follows:

1. Start and warm up the engine (see section **Starting/Stopping**).
2. With the outlet valves (2) closed, loosen the regulating valve's lock nut and adjust the regulating valve (1) until a pressure of X bar is reached (see table).
3. Check the minimum speed of the engine. Adjust minimum speed stop screw if necessary.
4. Open an outlet valve (2) sufficiently to let the engine run at maximum speed. The working pressure must be Y bar; adjust if necessary with regulating valve (1) (see table).
5. Check the engine maximum speed. Adjust the maximum speed by means of adjustable eccentric nut on top of speed regulator.
6. Close the outlet valves (2), check that the pressure is between Z1 and Z2 bar (see table). Lock the regulating valve (1) by fixing the lock nut.

AIR FILTER ENGINE/COMPRESSOR



- | | |
|------------------------------|---------------------|
| 1. Snap clips | 6. Vacuator valve |
| 2. Dust trap cover | 7. Vacuum indicator |
| 3. Safety cartridge (option) | 8. Reset button |
| 4. Filter element | 9. Yellow indicator |
| 5. Filter housing | |

CLEANING THE DUST TRAP

Remove dust daily.

To remove dust from the dust trap squeeze the vacuator valve (6) several times.

RECOMMENDATIONS



The Atlas Copco air filters are specially designed for the application. The use of non-original air filters may lead to severe damage of engine and/or compressor element.

Never run the compressor without air filter element.

New elements must also be inspected for tears or punctures before installation.

Discard the element (4) when damaged.

In heavy duty applications it is recommended to install a safety cartridge, which can be ordered with part no.: 2914 9311 00

A dirty safety cartridge (3) is an indication of a malfunctioning air filter element. In that case replace the element and safety cartridge.

The safety cartridge cannot be cleaned.

REPLACING THE AIR FILTER ELEMENT

1. Release the snap clips (1) and remove the dust trap (2). Clean the trap.
2. Remove the element (4) and the safety cartridge.
3. Reassemble in reverse order of dismantling. Make sure the vacuator valve (6) points down.
4. Inspect and tighten all air intake connections.
5. Reset the vacuum indicator by pressing the reset button (5).

AIR RECEIVER

The air receiver (1) is tested according to official standards. Carry out regular inspections in conformity with local regulations.

SAFETY VALVE




All adjustments or repairs are to be done by an authorized representative of the valve supplier.

Following checks must be carried out on the safety valve (2):

- a check of the opening of the lifting gear, twice a year. This can be done by screwing the cap of the valve anti-clockwise.
- an annual check of the set pressure according to local regulations. This check cannot be done on the machine and must be carried out on a proper test bench.

FUEL SYSTEM



Replacing the filter element

1. Unscrew the filter element (1) from the adapter head.
2. Clean the adapter head sealing surface. Lightly oil the gasket of the new element and screw the latter onto the header until the gasket is properly seated, then tighten with both hands.
3. Check for fuel leaks once the engine has been restarted.

FUEL

For fuel specifications, please contact your Atlas Copco Customer Center.

BRAKE (= OPTION) ADJUSTMENT



Before jacking up the compressor, connect it to a towing vehicle or attach a minimum weight of 50 kg (110 lb) to the towbar.

BRAKE SHOE ADJUSTMENT


Check the thickness of the brake lining. Remove both black plastic plugs (5), one on each wheel. When the brake lining has been worn down to a thickness of 1 mm (0.039 in) or less, the brake shoes have to be replaced. After inspection and/or replacement re-insert both plugs.

Brake shoe adjustment re-establishes the brake lining-to-drum clearance and compensates for lining wear.

Lift and support the compressor. Make sure that all brakes are off (overrunbrake and hand brake lever). The brake cables must be free from tension. Lock the swivel cams of the wheel brake from the outside by means of a pin ~ 4 mm (4) through the hole as shown in the Figure.

Turn the adjusting bolt (1) clockwise with a wrench till the wheel locks up. Center the brake shoes by actuating the parking brake several times.

Turn the adjusting bolt anti-clockwise until the wheel is running free in direction of travel (approx. 1 full turn of the adjusting bolt).



- | | |
|-------------------|---------------|
| 1. Adjusting bolt | 4. Pin ~ 4 mm |
| 2. Axle | 5. Plug |
| 3. Brake cable | |

Check the position of the equalizer (see section **Brake cable adjustment**, 6) with the parking brake actuated.

Perpendicular position of equalizer = identical clearance of wheel brakes.


Re-adjust the brake shoes, if necessary.

To test, slightly apply the parking brake and check identical brake torque on left and right side.

Remove locking pin (4). Remove clearance from brake cables.

Check all lock nuts (**Brake cable adjustment**, 2).


TEST PROCEDURE OF BRAKE CABLE ADJUSTMENT



Correct and wrong position of markings

1. Check if the towing eye rod of the overrun brake mechanism is in the outmost position.
2. Check if the adjustable towbar (= option) is in the actual towing position.
3. Apply the hand brake lever.
4. Push the compressor a few centimeters backwards so that the brake lever is automatically pulled up further.
5. Check the position of the arrow marking "1" at the catch lock in combination with the arrow marking "2" at the toothed sector, according to A,B,C,D.

BRAKE CABLE ADJUSTMENT




- | | |
|------------------|---------------------|
| 1. Brake cable | 4. Brake cable nut |
| 2. Lock nut | 5. Main brake cable |
| 3. Adjusting nut | 6. Equalizer |

1. With the towing eye pulled out in the outmost position and the hand brake lever in the downward position (see Figure), loosen the lock nuts (2). Turn adjusting nuts and brake cable nuts (4) clockwise until there is no slack in the brake mechanism.

The equalizer (6) must remain perpendicular to main brake cable (5).

2. Apply the hand brake lever several times and repeat the adjustment. Tighten the nuts with their lock nuts (2). Remove the jack and the blocks.
3. Road test the compressor and brake several times. Check brake shoe and brake cable adjustment and adjust if necessary.



Hand brake lever downward - brake not operated

WHEELS


WHEEL CHECK

- Check wheel bolts for firm seating (initially)
- Check hub caps for firm seating (every 2,500 km or annually)
- Check tyres for uneven wear (every 2,500 km or annually)
- Check lateral play of wheel bearing. If necessary, readjust.

Compact bearings (every 2 years)

Conventional bearings (after 500 km, every 2,500 km or annually)

LUBRICATION



Tapered type hub cap

Taper roller bearings and deep groove ball bearing

Axles fitted with taper roller bearings are recognizable by a tapered type hub cap, see Figure.


Remove wheels and wheel hubs.

Mark dismantled wheel hubs and bearing races so that their identity is not mistaken during reassembly.

Clean wheel hubs thoroughly inside and outside. Remove old grease totally.

Clean taper roller bearings and seals (using diesel oil) and check for reusability.

Work BPW special longlife grease ECO_Li 91 into the cavities between the taper roller and cage. Smear grease into the hub's outer bearing race.




Greasing bearing race

Fill the hub caps to 3/4 full with grease.

Fit wheel hubs, adjust the bearing play and fit the hub caps.

WHEEL BOLTS CHECK




Cylindrical hub cap shape

Compact bearings

Compact bearings are recognizable by cylindrical hub cap shape, see Figure.

Compact bearings are maintenance-free due to permanent lubrication and are designed for high mileages.

Therefore, there is no grease change or regreasing necessary.



Wheel bolts tightening




After the first run, likewise after each wheel change.

Tighten wheel bolts crosswise using a torque wrench and tightening torque in compliance with the table.

Tightening torques of wheel bolts

Spanner width (mm)	Thread	Tightening torque Nm (lbf.ft)
19	M 12x1.5	110 (81)
24	M 18x1.5	280 (207)

WHEEL BEARING ADJUSTMENT



Bearing play

Jack up the compressor, release brakes.

Turn wheels manually and rock.

If any bearing play is perceivable, adjust the bearings.

Conventional taper roller bearings

Taper roller bearings are recognisable by the conical profile of the hub cap.

- Lever off hub cap. Remove split pin from axle nut and tighten so that rotation of the wheel is slightly braked.
- Turn back the axle nut to the next possible split pin hole, by a maximum of 30 degrees.
- Insert split pin and bend ends slightly outwards.
- Check wheel rotation, fit hub cap.

Important:

The grease in the hub cap and bearing must not be contaminated with dirt during this job!

Compact bearings

Compact bearings are recognizable by their cylindrical hub cap shape.



If noticeable bearing play is felt, the compact bearings should be replaced.

TOWBAR AND OVERRUN BRAKE

TOWBAR AND OVERRUN BRAKE CHECK

Check coupling head




First initially, then every 5,000 kilometres or annually.

Check coupling head for wear and correct operation.

Check the wear indicator (use within the "+" range only).

Check the coupling head fastenings (see arrows, Figure) at regular intervals for firm seating.



Check the coupling head fastenings

Check height adjustment facility



Initially, before every journey, up to 500 kilometres, then every 5,000 kilometres or annually.


After every adjustment the clamping nuts must be tightened and secured with the spring elements.

Tightening torque:

M 24 = 250 - 350 Nm

M 32 = 350 - 400 Nm

Check tight fit of the clamping nuts and correct positioning of the adjustment facility.



Brake play check

Brake play check




After the first run, then every 2,000 - 3,000 kilometres.

The check is carried out visually on the stroke (x) of the overrun coupling.

As soon as this is more than 50 mm when the brakes are applied, adjust the wheel brakes.

Check towbar, handbrake lever, spring actuator, reversing lever, linkage and all movable parts for ease of movement.

LUBRICATION




Towbar



First initially, then every 5,000 kilometres or annually.

Check safety cable (1) for damage; every 5,000 kilometres or annually.

Check Bowden cable (2) on height-adjustable connection devices for damage; every 5,000 kilometres or annually.



Lubrication coupling head


Lubricate the coupling head



At regular intervals.

Oil ball coupling at regular intervals in the specified locations and moving parts.

Grease the contact surface of the ball of the towing vehicle.




Greasing towbar

Towbar bushes on the housing of the overrun coupling



Initially, after 2,000 - 3,000 kilometres, every 5,000 kilometres.

Apply general purpose grease via the grease nipples until fresh grease can be seen emerging from the bushes.



Reversing lever

Reversing lever




Initially, after 2,000 - 3,000 kilometres, every 5,000 kilometres.

Check reversing lever (1) for ease of motion.

If fitted, apply general purpose grease via the grease nipple until fresh grease can be seen emerging from the bush.

If grease nipples are not fitted, then apply oil to the reversing lever bush.




Lubrication points

Lubricate all moving parts and pivot pins at the overrun coupling



Initially, after 2,000 - 3,000 kilometres, every 5,000 kilometres.

All moving parts of drawbar, handbrake lever, spring actuator, reversing lever, linkages etc. are to be oiled or greased as required.



Height adjusting device

Grease sliding locations on the height-adjusting device



For the first time after 2,000 - 3,000 kilometres travelled, then every 5,000 kilometres.

Oil threaded parts and grease toothed parts.

Problem solving

It is assumed that the engine is in good condition and that there is adequate fuel flow to the filter and injection equipment.

Make sure that the wires are not damaged and that they are clamped tight to their terminals.



An electrical fault must be traced by an electrician.



For position of dip switches refer to section Electrical system.

Problem	Possible faults	Corrective actions
1. Starter motor does not crank engine after switching startbutton (S) to "ⓘ".	a. Low battery output.	a. Check electrolyte level and charge battery. If no cells are shorted and battery is discharged, trace cause and correct.
2. Starter motor cranks engine when switching start button (S) to "ⓘ", but engine does not fire.	a. Low battery output.	a. See corrective action 1.
3. Engine fires, but engine stops when releasing start button (S).	a. Alternator drive belt broken or slipping. b. Alternator/regulator defective.	a. Check and correct if necessary. b. Have assembly repaired.
4. Hourmeter (P1) does not count running time.	a. Hourmeter (P1) defective.	a. Replace.
5. Engine is running, but shuts down immediately after start button (S) has been released.	a. Start button (S) released too soon. b. Insufficient engine oil pressure. c. Fuel tank contains insufficient fuel.	a. Release button after engine oil pressure has built up above the minimum allowed level. b. Stop at once, consult the engine instruction manual. c. Fill fuel tank.
6. Compressor is loaded automatically to full capacity after starting.	a. Loading valve stuck in loading position. b. Air intake throttle valve stuck in opened position. c. Air leaks in regulating system.	a. Remove and dismantle loading valve. Correct if necessary. b. Check and, if necessary consult Atlas Copco. c. Check hoses and their fittings. Stop leaks; replace leaking hoses.

Problem	Possible faults	Corrective actions
7. Unit does not load after pressing the loading button.	a. Regulating valve defective.	a. Check and if necessary consult Atlas Copco.
8. Engine does not speed up immediately after compressor loading valve button has been pressed and compressor does not deliver air.	a. Regulating valve defective. b. Air intake throttle valve stuck in closed position.	a. Check and, if necessary consult Atlas Copco. b. Check and, if necessary consult Atlas Copco.
9. Excessive compressor oil consumption. Oil mist being discharged from air outlet valves.	a. Compressor oil level too high.	a. Check oil level. Release pressure and drain oil to correct level.
10. Compressor capacity or pressure below normal.	a. Air consumption exceeds capacity of compressor. b. Choked air filter elements. c. Unloading valve not completely open.	a. Check equipment connected. b. Remove and inspect elements. c. Check and, if necessary consult Atlas Copco.
11. Compressor does not unload and engine keeps running at max. speed when closing the air outlet valves, safety valve blows.	a. Regulating valve incorrectly set or defective. b. Air leaks in regulating system. c. Unloading valve stuck.	a. Check and, if necessary consult Atlas Copco. b. Check hoses and their fittings. Stop leaks and, if necessary consult Atlas Copco. c. Check and, if necessary consult Atlas Copco.
12. Working pressure rises during operation and causes safety valve to blow.	a. Regulating valve incorrectly set or defective. b. Air leaks in regulating system. c. Unloading valve stuck. d. Safety valve defective.	a. Check and, if necessary consult Atlas Copco. b. Check hoses and their fittings. Stop leaks and, if necessary consult Atlas Copco. c. Check and, if necessary consult Atlas Copco. d. Check safety valve; consult Atlas Copco.
13. After working some time, the unit stops through a shutdown switch.	a. Fuel tank contains insufficient fuel. b. Air in fuel system, or insufficient fuel supply. c. Engine oil pressure too low. d. Engine temperature too high. e. Compressor temperature too high. f. Low coolant level.	a. Fill fuel tank. b. Check filters and hoses for leaks, dirt and bends. c. Refer to the engine instruction manual. d. See corrective actions 15. e. See corrective actions 16. f. Top up cooling system.

Problem	Possible faults	Corrective actions
14. Air and oil mist expelled from air filters immediately after stopping.	a. Unloader valve jammed. b. Wrong oil type (without foam-retarding additives).	a. Check and, if necessary consult Atlas Copco. b. Consult Atlas Copco.
15. Engine overheating.	a. Insufficient engine cooling. b. Engine oil cooler clogged externally.	a. Relocate compressor. b. Clean engine oil cooler. Refer to section Cleaning coolers .
16. Compressor overheating.	a. Insufficient compressor cooling. b. Oil cooler clogged externally. c. Oil level too low.	a. Locate compressor away from walls; when banked with other compressors, leave space between them. b. Clean oil cooler. Refer to section Cleaning coolers . c. Check oil level. Top up with recommended oil.
17. After working for some time, the unit stops for no apparent reason.	a. Air in fuel system, or insufficient fuel supply.	a. Check filters and hoses for leaks, dirt and bends.

Alternator precautions

1. Never reverse the polarity of the battery or the alternator.
2. Never break any alternator or battery connections while the engine is running.
3. When recharging the battery, disconnect it from the alternator. Before using booster cables to start the engine, be sure of the polarity and connect the batteries correctly.
4. Never operate the engine without the main or voltage sensing cables connected in the circuit.

Available options

Vessel type:	EURO
	ASME
Towbar:	Adjustable with brakes (A)
	Fixed with brakes (A)
	Fixed without brakes
Without towbar:	Support (without undercarriage)
Towing eyes:	Atlas Copco
	DIN
	Ball
	Italian
	GB
	NATO
	AC (France)
Towbar support:	Support leg
	Jockey wheel
Road signalisation:	Full (B)
Safety:	Wheel chocks
	Safety cartridge
Refinery equipment:	Spark arrestor
	Inlet shut down valve

Air quality equipment:	Aftercooler + water separator
	Aftercooler + water separator + fine filter PD
	Aftercooler + water separator + fine filter PD + QD
	Aftercooler + water separator + fine filter PD + reheater (C)
	Aftercooler + water separator + fine filter PD + QD + reheater (C)
	Aftercooler + water separator + reheater
	Lubricator on 7 bar units
Safety:	Wheel chocks
	Safety cartridge
Refinery equipment:	Spark arrestor
	Inlet shut down valve
Cold start:	-20 °C (-4 °F)
Customer colour:	Single
	Double
	Triple

- A. These units meet your local safety regulations and are available with overrun and parking brakes.
- B. Reflectors and lights for safety on the road.
- C. Quality air through the aftercooler, reheater and fine filters.

Technical specifications

TORQUE VALUES

FOR GENERAL APPLICATIONS

The following tables list the recommended torques applied for general applications during assembly of the compressor.

For hexagon screws and nuts with strength grade 8.8

Thread size	Torque value (Nm / lbf.ft)
M6	8 (6) +/-25 %
M8	20 (15) +/-25 %
M10	41 (30) +/-25 %
M12	73 (54) +/-25 %
M14	115 (85) +/-25 %
M16	185 (137) +/-25 %

For hexagon screws and nuts with strength grade 12.9

Thread size	Torque value (Nm / lbf.ft)
M6	14 (10) +/-21 %
M8	34 (25) +/-23 %
M10	70 (52) +/-24 %
M12	120 (89) +/-25 %
M14	195 (144) +/-23 %
M16	315 (233) +/-23 %

CRITICAL TORQUE VALUES

Assemblies	Torque value (Nm / lbf.ft)
Wheel bolts	see section Wheel bolts check
Bolts, axle/beams	80 (59) +/- 10 %
Bolts, towbar/axle	80 (59) +/- 10 %
Bolts, towbar/bottom	80 (59) +/- 10 %
Bolts, towing eye/towbar	80 (59) +/- 10 %
Bolts, lifting eye/flywheel housing	80 (59) +/- 10 %
Bolts, engine/drive housing (M12)	80 (59) +/- 10 %
Bolts, engine/drive housing (M14)	125 (92) +/- 10 %
Bolts, compressor element/drive housing	80 (59) +/- 5 %
Safety switches	35 (26) +/- 5 %



Secure the drain cock and tank cap of the fuel tank handtight.

SETTINGS OF SHUTDOWN SWITCHES AND SAFETY VALVES

Designation		XAHS 146 Dd XAHS 300 DD6 COM3	XATS 156 Dd XATS 350 DD6 COM3	XA(S) 186 Dd XA(S) 375 DD6 COM3	XAVS 166 Dd XAVS 340 DD6 COM3	XAHS 186 Dd XAHS 375 DD6 COM3	XATS 156 Dd XATS 350 DD6 COM2	XA(S) 186 Dd XA(S) 375 DD6 COM2
Engine oil pressure	bar	2	2	2	2	2	-	-
	psi	29	29	29	29	29	-	-
Engine oil temperature	°C	113	113	113	113	113	-	-
	°F	235	235	235	235	235	-	-
Compressor temperature	°C	120	120	120	120	120	-	-
	°F	248	248	248	248	248	-	-
Safety valve opening pressure								
- EC type	bar	15	13.5	10	17	17	13.5	10
- ASME type	psi	218	200	150	250	250	200	150

COMPRESSOR/ENGINE/GENERATOR SPECIFICATIONS

REFERENCE CONDITIONS

Designation		XAHS 146 Dd XAHS 300 DD6 COM3	XATS 156 Dd XATS 350 DD6 COM3	XA(S) 186 Dd XA(S) 375 DD6 COM3	XAVS 166 Dd XAVS 340 DD6 COM3	XAHS 186 Dd XAHS 375 DD6 COM3	XATS 156 Dd XATS 350 DD6 COM2	XA(S) 186 Dd XA(S) 375 DD6 COM2
Absolute inlet pressure	bar	1	1	1	1	1	1	1
	psi	14.5	14.5	14.5	14.5	14.5	14.5	14.5
Relative air humidity	%	0	0	0	0	0	0	0
Air inlet temperature	°C	20	20	20	20	20	20	20
	°F	68	68	68	68	68	68	68
Nominal effective working pressure	bar	12	10.5	7	14	12	10.3	7
	psi	174	152	102	203	174	149	102

The inlet conditions are specified at the air inlet grating outside the canopy.

LIMITATIONS

Designation		XAHS 146 Dd XAHS 300 DD6 COM3	XATS 156 Dd XATS 350 DD6 COM3	XA(S) 186 Dd XA(S) 375 DD6 COM3	XAVS 166 Dd XAVS 340 DD6 COM3	XAHS 186 Dd XAHS 375 DD6 COM3	XATS 156 Dd XATS 350 DD6 COM2	XA(S) 186 Dd XA(S) 375 DD6 COM2
Minimum effective receiver pressure	bar	4	4	4	4	4	4	4
	psi	58	58	58	58	58	58	58
Maximum effective receiver pressure, compressor unloaded	bar	13.5	11.8	8.5	15.5	13.5	11.8	8.5
	psi	196	171	123	225	196	171	123
Maximum ambient temperature at sealevel	no aftercooler	°C	50	50	50	45	45	50
		°F	122	122	122	113	113	122
	with aftercooler	°C	49	47	47	40	40	-
		°F	114	114	114	104	104	-
Minimum starting temperature	no aftercooler	°C	-10	-10	-10	-10	-10	-10
		°F	14	14	14	14	14	14
	with aftercooler	°C	-20	-20	-20	-20	-20	-20
		°F	-4	-4	-4	-4	-4	-4

PERFORMANCE DATA

At reference conditions, if applicable, and at normal shaft speed, unless otherwise stated.

Designation		XAHS 146 Dd XAHS 300 DD6 COM3	XATS 156 Dd XATS 350 DD6 COM3	XA(S) 186 Dd XA(S) 375 DD6 COM3	XAVS 166 Dd XAVS 340 DD6 COM3	XAHS 186 Dd XAHS 375 DD6 COM3	XATS 156 Dd XATS 350 DD6 COM2	XA(S) 186 Dd XA(S) 375 DD6 COM2
Engine shaft speed, normal and maximum	r/min	2300	2300	2300	2200	2200	2300	2300
Engine shaft speed, compressor unloaded	r/min	1700	1700	1700	1700	1700	1700	1700
Free air delivery ¹⁾	standard	l/s	151	161	185	158	173	166
		cfm	320	341	392	335	367	352
	with aftercooler	l/s	147	157	181	154	169	-
		cfm	311	333	384	326	358	-

¹⁾ Free Air Delivery (volume flow rate) is measured according to ISO 1217 ed.3 1996 annex D

Tolerance:

- +/- 5% 25 l/s (53 cfm) < FAD < 250 l/s (530 cfm)
- +/- 4% 250 l/s (530 cfm) < FAD

The international standard ISO 1217 corresponds to following national standards:

- British BSI 1571 part 1
- German DIN 1945 Part 1
- Swedish SS-ISO 1217
- American ANSI PTC9

Fuel consumption

Designation		XAHS 146 Dd XAHS 300 DD6 COM3	XATS 156 Dd XATS 350 DD6 COM3	XA(S) 186 Dd XA(S) 375 DD6 COM3	XAVS 166 Dd XAVS 340 DD6 COM3	XAHS 186 Dd XAHS 375 DD6 COM3	XATS 156 Dd XATS 350 DD6 COM2	XA(S) 186 Dd XA(S) 375 DD6 COM2
at 100% FAD	kg/h	18.1	18	17.4	21.2	21	18.3	17.4
	lb/h	39.9	39.7	38.4	46.7	46.3	40.34	38.36
at unload	kg/h	-	-	-	-	-	9.6	8.5
	lb/h	-	-	-	-	-	21.17	18.74
Specific fuel consumption								
at 100% FAD standard	g/m ³	33.1	30.6	26.1	35.8	33.5	30.3	26
	lb/10 ³ cu.ft	2.07	1.91	1.63	2.24	2.09	1.88	1.62
Typical oil content of compressed air	mg/m ³	< 5	< 5	< 5	< 5	< 5	< 5	< 5
	oz/10 ³ cft	< 0.005	< 0.005	< 0.005	< 0.005	< 0.005	< 0.005	< 0.005
Engine oil consumption (maximum)	g/h	18.2	17.8	17.4	20.8	20.9	14	14
	oz/h	0.64	0.63	0.61	0.73	0.74	0.49	0.49
Compressed air temperature standard at outlet valves	°C	90	90	90	95	95	90	90
	°F	194	194	194	203	203	194	194
	with aftercooler	°C	ambient + 9	ambient + 9	ambient + 9	ambient + 9	-	-
		°F	ambient + 16	ambient + 16	ambient + 16	ambient + 16	-	-
Sound pressure level (LP), measured according to ISO 2151 under free field conditions at 7 m distance	dB(A)	71	71	71	71	71	72	71
Sound power level (Lw) complies with 2000/14/EC	dB(A)	99	99	99	99	99	100	99

DESIGN DATA

Compressor

Designation	
Number of compression stages	1

Engine

Designation		XAHS 146 Dd XAHS 300 DD6 COM3	XATS 156 Dd XATS 350 DD6 COM3	XA(S) 186 Dd XA(S) 375 DD6 COM3	XAVS 166 Dd XAVS 340 DD6 COM3	XAHS 186 Dd XAHS 375 DD6 COM3	XATS 156 Dd XATS 350 DD6 COM2	XA(S) 186 Dd XA(S) 375 DD6 COM2
Make		Deutz	Deutz	Deutz	Deutz	Deutz	Deutz	Deutz
Type		TCD2012LO4	TCD2012LO4	TCD2012LO4	TCD2013LO4	TCD2013LO4	BF4M2012C	BF4M2012C
Coolant		Liquid	Liquid	Liquid	Liquid	Liquid	Liquid	Liquid
Number of cylinders		4	4	4	4	4	4	4
Bore	mm	101	101	101	108	108	101	101
	in	3.98	3.98	3.98	4.25	4.25	3.98	3.98
Stroke	mm	126	126	126	130	130	126	126
	in	4.96	4.96	4.96	5.12	5.12	4.96	4.96
Swept volume	l	4.038	4.038	4.038	4.764	4.764	4.038	4.038
	cu.in	246.4	246.4	246.4	251.2	251.2	246.4	246.4
Output according to SAE J1995 at normal shaft speed	kW	83	83	83	104	104	90	90
	BHP	113	113	113	141	141	122	122
- Load factor	%	65	65	65	65	65	70	70
Capacity of oil sump:								
- Initial fill	l	9	9	9	12	12	8.5	8.5
	US gal	2.2	2.2	2.2	2.9	2.9	2.0	2.0
- Refill (max.) ¹⁾	l	8.5	8.5	8.5	11.5	11.5	8	8
	US gal	2.0	2.0	2.0	2.8	2.8	1.9	1.9
Capacity of cooling system	l	14	14	14	16	16	14	14
	US gal	3.4	3.4	3.4	3.9	3.9	3.4	3.4

¹⁾ With filter change.

Unit

Designation		XAHS 146 Dd - XAHS 300 DD6 XATS 156 Dd - XATS 350 DD6 XA(S) 186 Dd - XA(S) 375 DD6 XAVS 166 Dd - XAVS 340 DD6 XAHS 186 Dd - XAHS 375 DD6 XATS 156 Dd - XATS 350 DD6 XA(S) 186 Dd - XA(S) 375 DD6
Capacity of compressor oil system	l	24
	US gal	5.9
Net capacity of air receiver	l	42
	US gal	10.3
Capacity of fuel tank	l	175
	US gal	43
Air volume at inlet grating (approx.) ¹⁾	m ³ /s	3.9
	cfm	8300

¹⁾ Air required for engine and compressor cooling, for combustion and for compression.

Unit dimensions

with brakes		towbar	
		fixed	adjustable
Length	mm	3941	4356
	in	155.2	171.5
Width	mm	1716	1716
	in	67.6	67.6
Height	mm	1661	1661
	in	65.4	65.4
Weight (ready-to-operate)	kg	1800	1825
	lb	3970	4025

Data plate

The diagram shows a data plate with the following fields and components:

- (1) Company code
- (2) Product code
- (3) Unit serial number
- (4) Name of the manufacturer
- (5) EEC or national type approval number
- (6) Vehicle identification number
- (7) Undercarriage
 - A kg
 - B kg
 - C kg
 - D kg
- (8) Model
- (9) Working pressure
- (10) Speed
- (11) Engine power
- (12) Manufacturing year
- (13) CE mark in accordance with Machine Directive 89/392 EC
- (14) Register number or number of notified body

The data plate also includes the text: Atlas Copco Airpower n.v., Boomsesteenweg 957, B-2610, WILRIJK, and the Atlas Copco logo.

- 1 Company code
- 2 Product code
- 3 Unit serial number
- 4 Name of the manufacturer
- 5 EEC or national type approval number
- 6 Vehicle identification number
- 7 Undercarriage
 - A** Maximum permitted total weight of the vehicle
 - B** Maximum permitted load on the towing eye
 - C** Maximum permitted load on axle (or front axle on dual axle units)
 - D** Maximum permitted load on rear axle (on dual axle units)
- 8 Model
- 9 Working pressure
- 10 Speed
- 11 Engine power
- 12 Manufacturing year
- 13 CE mark in accordance with Machine Directive 89/392 EC
- 14 Register number or number of notified body

Disposal

GENERAL

When developing products and services, Atlas Copco tries to understand, address, and minimize the negative environmental effects that the products and services may have, when being manufactured, distributed, used and disposed.

Recycling and disposal policy are part of the development of all Atlas Copco products. Atlas Copco company standards determine strict requirements.

Material selection, substantial recyclability, disassembly possibilities and separability of materials and assemblies are considered, as well as environmental perils and dangers to health during the recycling and disposal of the unavoidable rates of non-recyclable materials.

Your Atlas Copco compressor consists for the most part of metallic materials, that can be remelted in steelworks and smelting works and are therefore almost infinitely recyclable. The plastic used is labelled; sorting and fractioning of the materials for recycling in the future is foreseen.



This concept can only succeed with your help. Support us by disposing professionally. By assuring correct disposal of the product you help prevent possible negative consequences for environment and health as a result of inappropriate waste handling.

Recycling and re-usage of material help preserve natural resources.

DISPOSAL OF MATERIALS

Dispose of contaminated substances and material separately, in accordance with locally applicable environmental legislation.

Before dismantling a machine at the end of its operating lifetime drain and dispose of all fluids of according the applicable local disposal regulations.

Remove the batteries. Do not throw batteries into the fire (explosion risk) or residual waste. Separate the machine into metal, electronics, wiring, hoses, insulation and plastic parts.

Dispose of all components in accordance with applicable disposal regulations.

Remove spilled fluid mechanically; pick up the rest using an absorbing agent (for example sand, sawdust) and dispose of it in accordance with local disposal regulations. Do not drain into the sewage system or surface water.

Maintenance Log

Compressor Customer

Serial number

Service hours	Maintenance action	Date	By: initials



Following documents are provided with this unit:

- Test Certificate
- EC Declaration of Conformity:

Atlas Copco

EC DECLARATION OF CONFORMITY

1 We, Atlas Copco Airpower n.v., declare under our sole responsibility, that the product

2 Machine name : **Compressor (< 350 kW)**

3 Commercial name :

4 Serial number :

5 Which falls under the provisions of article 12.2 of the EC Directive 2006/42/EC on the approximation of the laws of the Member States relating to machinery, is in conformity with the relevant Essential Health and Safety Requirements of this directive.

The machinery complies also with the requirements of the following directives and their amendments as indicated.

6	7	8	9	10
	Directive on the approximation of laws of the Member States relating to	Harmonized and/or Technical Standards used	Att' ment	
11	Pressure equipment	97/23/EC	EN ISO 12100-1 EN ISO 12100-2 EN 1012-1	X
12	Machinery safety	2006/42/EC		
13	Simple pressure vessel	87/404/EEC		X
14	Electromagnetic compatibility	2004/108/EC	EN 61000-6-2 EN 61000-6-4	
15	Low voltage equipment	2006/95/EC	EN 60034 EN 60204-1 EN 60439	
16	Outdoor noise emission	2000/14/EC	ISO 3744	X

17 The harmonized and the technical standards used are identified in the attachments hereafter

18 Atlas Copco Airpower n.v. is authorized to compile the technical file

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

275

276

277

278

279

280

281

282

283

284

285

286

287

288

289

290

291

292

293

294

295

296

297

298

299

300

301

302

303

304

305

306

307

308

309

310

311

312

313

314

315

316

317

318

319

320

321

322

323

324

325

326

327

328

329

330

331

332

333

334

335

336

337

338

339

340

341

342

343

344

345

346

347

348

349

350

351

352

353

354

355

356

357

358

359

360

361

362

363

364

365

366

367

368

369

370

371

372

373

374

375

376

377

378

379

380

381

382

383

384

385

386

387

388

389

390

391

392

393

394

395

396

397

398

399

400

401

402

403

404

405

406

407

408

409

410

411

412

413

414

415

416

417

418

419

420

421

422

423

424

425

426

427

428

429

430

431

432

433

434

435

436

437

438

439

440

441

442

443

444

445

446

447

448

449

450

451

452

453

454

455

456

457

458

459

460

461

462

463

464

465

466

467

468

469

470

471

472

473

474

475

476

477

478

479

480

481

482

483

484

485

486

487

488

489

490

491

492

493

494

495

496

497

498

499

500

501

502

503

504

505

506

507

508

509

510

511

512

513

514

515

516

517

518

519

520

521

522

523

524

525

526

527

528

529

530

531

532

533

534

535

536

537

538

539

540

541

542

543

544

545

546

547

548

549

550

551

552

553

554

555

556

557

558

559

560

561

562

563

564

565

566

567

568

569

570

571

572

573

574

575

576

577

578

579

580

581

582

583

584

585

586

587

588

589

590

591

592

593

594

595

596

597

598

599

600

601

602

603

604

605

606

607

608

609

610

611

612

613

614

615

616

617

618

619

620

621

622

623

624

625

626

627

628

629

630

631

632

633

634

635

636

637

638

639

640

641

642

643

644

645

646

647

648

649

650

651

652

653

654

655

656

657

658

659

660

661

662

663

664

665

666

667

668

669

670

671

672

673

674

675

676

677

678

679

680

681

682

683

684

685

686

687

688

689

690

691

692

693

694

695

696

697

698

699

700

701

702

703

704

705

706

707

708

709

710

711

712

713

714

715

716

717

718

719

720

721

722

723

724

725

726

727

728

729

730

731

732

733

734

735

736

737

738

739

740

741

742

743

744

745

746

747

748

749

750

751

752

753

754

755

756

757

758

759

760

761

762

763

764

765

766

767

768

769

770

771

772

773

774

775

776

777

778

779

780

781

782

783

784

785

786

787

788

789

790

791

792

793

794

795

796

797

798

799

800

801

802

803

804

805

806

807

808

809

810

811

812

813

814

815

816

817

818

819

820

821

822

823

824

825

826

827

828

829

830

831

832

833

834

835

836

837

838

839

840

841

842

843

844

845

846

847

848

849

850

851

852

853

854

855

856

857

858

859

860

861

862

863

864

865

866

867

868

869

870

871

872

873

874

875

876

877

878

879

880

881

882

883

884

885

886

887

888

889

890

891

892

893

894

895

896

897

898

899

900

901

902

903

904

905

906

907

908

909

910

911

912

913

914

915

916

917

918

919

920

921

922

923

924

925

926

927

928

929

930

931

932

933

934

935

936

937

938

939

940

941

942

943

944

945

946

947

948

949

950

951

952

953

954

955

956

957

958

959

960

961

962

963

964

965

966

967

968

969

970

971

972

973

974

975

976

977

978

979

980

981

982

983

984

985

986

987

988

989

990

991

992

993

994

995

996

997

998

999

1000

1001

1002

1003

1004

1005

1006

1007

1008

1009

1010

1011

1012

1013

1014

1015

1016

1017

1018

1019

1020

1021

1022

1023

1024

1025

1026

1027

1028

1029

1030

1031

1032

1033

1034

1035

1036

1037

1038

1039

1040

1041

1042

1043

1044

1045

1046

1047

1048

1049

1050

1051

1052

1053

1054

1055

1056

1057

1058

1059

1060

1061

1062

1063

1064

1065

1066

1067

1068

1069

1070

1071

1072

1073

1074

1075

1076

1077

1078

1079

1080

1081

1082

1083

1084

1085

1086

1087

1088

1089

1090

1091

1092

1093

1094

1095

1096

1097

1098

1099

1100

1101

1102

1103

1104

1105

1106

1107

1108

1109

1110

1111

1112

1113

1114

1115

1116

1117

1118

1119

1120

1121

1122

1123

1124

1125

1126

1127

1128

1129

1130

1131

1132

1133

1134

1135

1136

1137

1138

1139

1140

1141

1142

1143

1144

1145

1146

1147

1148

1149

1150

1151

1152

1153

1154

1155

1156

1157

1158

1159

1160

1161

1162

1163

1164

1165

1166

1167

1168

1169

1170

1171

1172

1173

1174

1175

1176

1177

1178

1179

1180

1181

1182

1183

1184

1185

1186

1187

1188

1189

1190

1191

1192

1193

1194

1195

1196

1197

1198

1199

1200

1201

1202

1203

1204

1205

1206

1207

1208

1209

1210

1211

1212

1213

1214

1215

1216

1217

1218

1219

1220

1221

1222

1223

1224

1225

1226

1227

1228

1229

1230

1231

1232

1233

1234

1235

1236

1237

1238

1239

1240

1241

1242

1243

1244

1245

1246

1247

1248

1249

1250

1251

1252

1253

1254

1255

1256

1257

1258

1259

1260

1261

1262

1263

1264

1265

1266

1267

1268

1269

1270

1271

1272

1273

1274

1275

1276

