REQUIRED SAFETY EQUIPMENT



SAFETY FIRST

If you are collecting the equipment for someone else please make sure this sheet is given to the equipment user to read. This sheet should be given to the site supervisor if the equipment is being hired for commercial use so that the information is available to all users.

Before starting any job, be sure to spend a few minutes planning and understanding the hazards and risks of the job. Do this by:

- Thinking about and observing your surroundings
- Running through the steps of the job in your mind
- Identifying the hazards, how you can get hurt and how you'll prevent it
- Knowing what plant and equipment you need
- Only starting when you can do the job safely
- Ensuring you are trained or experienced for the task
- Communicating with everyone involved

Points to consider when planning a task. Can you:

- Come into contact with an energy source (e.g. heat, electricity, substance under pressure) or hazardous materials
- Be struck-by or against anything?
- Be caught-in, on or between anything?
- Slip, trip or fall on the same or too a lower level
- Strain or sprain a muscle?
- Cause damage to plant equipment or property?
 Spill or pollute something?

Pre-Start Checks and Safety

This machine can cause serious injury if misused. Please read the following safety instructions carefully before operating the machine. This machine is designed to be operated by **one person only**, the person placing the wood into the splitter should be the same person operating the control lever. This ensures that hands are clear of the danger zone before the control is operated. Extreme pressure is exerted by the ram which may cause the wood to twist, trapping fingers or hands caused serious injury

- Check fuel tank is full (straight petrol)
- Check engine and hydraulic oil levels
- Set splitter up on a level site with stabilizer legs down and wheels chocked
- Ensure all logs are pre-cut into manageable lengths (with chainsaw)
- Do not hold wood whilst it is being split
- Continue to keep hands clear while the ram is in the return mode, the crust injury risk behind the ram is equal to that in front of the ram
- Keep children away from the machine at all times
- Always use in a well-ventilated area
- Ensure no body part or combustible material can come into contact with the engine exhaust
- Always stop engine before refueling
- Beware of loose clothing at all times



Starting Procedure

- 1. Turn on fuel supply and engine switch
- 2. Engage choke (cold start)
- Pull starter cord out until a slight resistance is felt, let starter recoil and give sharp pulls till engine fires or starts
- 4. Release choke
- If required re-pull starter cord out until a slight resistance is felt, let starter recoil and give sharp pulls till engine starts
- 6. Allow engine to warm up

When Operating

- Increase engine speed to full throttle
- Familiarise yourself with the ram control, it has a dead man valve fitted so the ram will stop as soon as the lever is released
- Place log on the splitting bench so that the hydraulic ram will pierce the centre of the log
- Always position the log to be split with the grain (never attempt to split across the grain as the log may burst or fly off splitting bench
- Only split one log at a time
- Remove hands from log before engaging the hydraulic ram
- Retract ram from split log and remove from bench before preparing for next log

THIS MACHINE IS ONLY TO BE OPERATED BY **ONE** PERSON

Log Splitter (towable) Instructions for Use