Defintions

1. Control Handle

The handle of the hedge trimmer held by the rear hand.

2. Trigger Switch Lockout

Must be depressed before the trigger switch can be activated.

3. Trigger Switch

Switches the motor on and off and controls the speed of the motor.

4. Retaining Latch

Locks or unlocks the trigger switch.

5. Battery Compartment

Accommodates the battery in the unit.

Switch Lever

Designed so that the cutting blades can only be activated if both it and the trigger switch are simultaneously in the depressed position. Located next to the front handle.

7. Loop Handle

For easy control of machine during cutting work.

8. Hand Guard

Limits useable grip area for front hand away from cutting blades. Helps protect hand from cuttings.

9. Battery Locking Tabs

Secure the battery in the unit.

10. Battery

Supplies the motor with electrical power.

11. Light Emitting Diodes (LED) on Battery

Indicate the state of charge and operating condition of the battery.

12. Push Button

For activating light emitting diodes (LED) on battery.

13. Blade Scabbard

Covers cutting blades when hedge trimmer is not in use.

14. Cutting Blades

Steel blades for cutting hedges and shrubs.

15. Charger

Charges the battery.

16. Light Emitting Diode (LED) on Charger

Indicates charger operating mode and certain problems.

17. Power Supply Cord

Supplies electric current to charger.

Specifications

Battery

Type: Lithium-ion Designation: AP, AR

The machine may be operated only with original STIHL AP and AR rechargeable batteries.

Power tool running time is dependent on the energy content of the battery.

STIHL AP series and AR series rechargeable batteries may be charged only with original STIHL AL series chargers.

Charger

AL 100

Power supply: 120 V / 60 Hz
Rated current: 1.3 A
Power consumption: 75 W
Charge current: 1.6 A

Insulation: II, (double insulated)

AL 300

Power supply: 120 V / 60 Hz

Rated current: 4.7 A

Power consumption: 330 W

Charge current: 6.5 A

Insulation: II. □ (d

II, □ (double insulated)

22 HSA 66

AL 500

Power supply: 120 V / 60 Hz
Rated current: 4.8 A
Power consumption: 570 W
Charge current: 12 A
Insulation: II, (double insulated)

Cutting Attachment

Tooth spacing: 1.2 in (30 mm)
Stroke rate: 3,000 rpm
Cutting length: 20" (500 mm)

Sharpening angle to horizontal: 35°

Weight

without battery, with cutting attachment, without blade scabbard

HSA 66: 6.8 lbs (3.1 kg)

Transporting Batteries

STIHL batteries comply with the requirements set forth in UN-Manual ST/SG/AC.10/11/Rev.5/Part III, Subsection 38.3.

Commercial air, vessel and ground transportation of lithium ion cells and batteries is regulated. The battery is classified as a UN 3480, Class 9, packaging group 2 product. Shipping it, either as a complete tool or the battery, requires compliance with all applicable shipping regulations. Check with the ground, vessel, air cargo or passenger

airline to determine if transport is prohibited or subject to restrictions or exemptions prior to shipping or travel.

Normally, no further conditions have to be fulfilled by the user to transport STIHL batteries by road to the power tool's operating site. Check and comply with any special regulations that may apply to your situation.

FCC 15 Compliance Statement for Power Tool and Charger

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- this device may not cause harmful interference.
- this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- reorient or relocate the receiving antenna,
- increase the separation between the equipment and receiver,
- connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- consult the dealer or an experienced radio/TV technician for help.

Do not change or modify this product in any way unless specifically allowed in this manual, since this could void your authority to operate it.

HSA 66 23